

零件表PARTS LIST WL-5120 / WL-5120C (兩用General / 水用Water Transport)

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
01	B010104050	曲軸箱 (紅)	CRANKCASE (RED)	1		12	B010916010	曲軸油封	CRANKSHAFT OIL SEAL	2	
	B010104051	曲軸箱 (藍)	CRANKCASE (BLUE)			13	B010504110	柱塞銷	PISTON PIN	3	
01-1	B012904000	汽缸銷	SET PIN	2		14A	B010404050	不鏽鋼柱塞	SST PISTON	3	
02	B011404000	防塵蓋	DUSTPROOF CAP	1			B013004002	陶瓷柱塞組	CERAMIC PISTON ASSY		
03	B011004000	曲軸油封蓋	CRANKSHAFT OIL SEAL COVER	2		14	B013104000	柱塞桿	PISTON	3	
03-1	BS11110013222	六角螺絲附華司	SET BOLT W/ WASHER	8		14-1	B013204030	柱塞套	PISTON SLEEVE	3	
03-2	B011104000	曲軸油封蓋 (套筒)	CRANKSHAFT OIL SEAL COVER (CONE)	1		14-2	B013304030	柱塞套固定螺絲	PISTON SCREW	3	
04A	B011901014	加油蓋組	OIL INLET COVER ASSY	1		14-4	BG30241030	背托環	BACK-UP RING	3	
05	B011704001	後蓋迫緊	REAR COVER PACKING	1		14-5	BG10237030700	O形環	O-RING	3	
06	B011604000	曲軸箱後蓋 (紅)	REAR COVER (RED)	1		14-6	B013504000	柱塞套平墊圈	GASKET	3	
	B011604310	曲軸箱後蓋 (藍)	REAR COVER (BLUE)			14-7	B013404030	柱塞套固定螺帽	SET NUT	3	
06-1	BS12108016100	大扁頭螺絲	SCREW	7		15	B010304000	腳座	CRANKCASE STAND	2	
07A	B012201003	油鏡組	OIL WINDOW ASSY	1		15-1	BS11116025200	六角螺絲	SET BOLT	4	
07	B012201020	油鏡	OIL WINDOW	1			BS32116200	彈簧華司	SPRING WASHER	4	
07-1	BG10234028700	O形環	O-RING	1		16	B010204000	柱塞油封	PISTON OIL SEAL	3	
08A	B011801001	排油螺絲組	DRAINAGE SCREW ASSY	1		17	B011204010	柱塞中間皮	WATERPROOF RING	3	
08	B011801000	排油螺絲	DRAINAGE SCREW	1		18	B014904020	曲軸箱固定螺絲	CRANKCASE SCREW	2	
08-1	BG10110015	O形環	O-RING	1		18-1	BS15114059200	雙頭牙螺絲	DOUBLE-END SCREW	2	
09	B010804120	曲軸	CRANKSHAFT	1		19-1	BS21114300	六角螺帽	NUT	4	
09-1	B012104000	曲軸鍵	CRANKSHAFT KEY	1		19-2	BS32114300	彈簧華司	SPRING WASHER	4	
10A	B010604001	連桿組	CONNECTING ROD ASSY	3		20	B020104030	汽缸	CYLINDER	1	
10-1	N/A	連桿	CONNECTING ROD	3		20-1	BS11116050100	六角螺絲	SCREW	4	
10-2	BS11110044500	六角螺絲	SET BOLT	6			BS32116200	彈簧華司	SPRING WASHER	4	
10-3	BS31208501	平面華司	WASHER	6		21	B020304300	防水迫緊 (兩用)	WATERPROOF PACKING (GENERAL)	3	
10-4	BS32110501	彈簧華司	SPRING WASHER	6			B020304301	防水迫緊 (水用)	WATERPROOF PACKING (WATER TRANSPORT)		
11	B010704010	軸承	BEARING	2		21-1	B020304310	防水迫緊墊片	SPACER	3	

零件表PARTS LIST WL-5120 / WL-5120C (兩用General / 水用Water Transport)

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
22	B020504050	U迫緊固定環	SET RING	3		35	B030404000	空氣室	AIR CHAMBER	1	
22-1	BG10552060400	O形環	O-RING	3		35-1	BG10410049	O形環	O-RING	1	
23	B020304210	U迫緊墊片	SPACER	3							
24	B020304200	U迫緊 (兩用)	U-PACKING (GENERAL)	3		【兩用】 【GENERAL】					
	B020304201	U迫緊 (水用)	U-PACKING (WATER TRANSPORT)			*40A	B050003011	安全弁(不含調壓螺絲組)	SAFETY VALVE ASSY (W/O KNOB)	1	
25	B020604050	迫緊防脫片	SET SOCKET	1		ACC.	B150104021	吸水管組 1-3/4"*10尺	SUCTION HOSE ASSY	1	
26	B024102000	連接管	CONNECTING PIPE	2		ACC.	B150102001	吸水管組 1"*9尺	SUCTION HOSE ASSY	1	
26-1	BG10100014010	O形環	O-RING	4		ACC.	B150604010	過濾網申目	FILTER SOCKET	1	
27	BS15120100300	雙頭牙螺絲	DOUBLE-END SCREW	2		ACC.	B150904020	過濾網	FILTER	1	
27-1	BS21120200	六角螺帽	NUT	2		ACC.	BP12022360200	皮帶輪 12B2*36*6	PULLEY 12B2*36*6	1	
27-2	BS32120200	彈簧華司	SPRING WASHER	2		ACC.	BS11112032121	皮帶輪螺絲	PULLEY SET BOLT	1	
28A	B040004041	活門組	VALVE ASSY	6							
28-1	B040304020	活門帽	VALVE CAGE	6		【水用】 【FOR WATER TRANSPORT ONLY】					
28-2	BJ20403000	活門彈簧	VALVE SPRING	6		52	B031703000	迴水桿底座	OVERFLOW ROD SEAT	1	
28-3	B040104020	活門塞	VALVE PLUG	6		53	BG20250030	方形環	SQUARE RING	1	
28-4	B040204030	活門座	VALVE SEAT	6		54	BS11110025122	六角螺絲附華司	SET BOLT W/ WASHER	2	
28-5	B040404000	活門皮	VALVE PACKING	6		ACC.	B150404110	吸水螺帽	SUCTION NUT	1	
29/30	B031404031	進水室含銅接頭	SUCTION CHAMBER W/ CONNECTOR	1		ACC.	B150504120	吸水管申目	SUCTION HOSE SOCKET	1	
29-1	BS15120070100	雙頭牙螺絲	DOUBLE-END SCREW	2		ACC.	BG20420052030	方形環	SQUARE RING	1	
29-2	BS21120200	六角螺帽	NUT	2		ACC.	BP12022360200	皮帶輪 12B2*36*6	PULLEY 12B2*36*6	1	
29-3	BS32120200	彈簧華司	SPRING WASHER	2		ACC.	BS11112032121	皮帶輪螺絲	PULLEY SET BOLT	1	
31	B030204310	出水室	OUTLET CHAMBER	1							
32	B031604110	球形閥 13mm	BALL COCK 13mm	2							
33	B030704020	出水塞頭 PT1-1/2	PLUG PT1-1/2	1							
34	B250001031	壓力錶 (直)	PRESSURE GAUGE (STRAIGHT)	1		*40A零件表及展開圖請參閱第4頁。			*40A parts list & diagram please refer to page 4.		
	B031105000	壓力錶 (圓)	PRESSURE GAUGE (ROUND)						2020.03V		

零件表PARTS LIST 安全弁 B050003011 / SAFETY VALVE ASSEMBLY

WL-51/B2/160B/5120系列用

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
91	B050103000	迴水座	OVERFLOW CHAMBER	1	
*92	BS11110025122	六角螺絲附華司	SET BOLT W/ WASHER	2	
94	BG20320037	方形環	SQUARE RING	1	
95	B050603000	調壓把手	PRESSURE REGULATING HANDLE	1	
96	BS12108013100	大扁頭螺絲	SCREW	2	
99A	B051003001	壓力閥座組	VALVE SEAT ASSY	1	
99	B051703000	閥座套	VALVE SLEEVE	1	
100	B051003000	壓力閥座	VALVE SEAT	1	
101A	B050903001	壓力閥組	PRESSURE VALVE ASSY	1	
101	B050903000	壓力閥	PRESSURE VALVE	1	
102	B051603000	壓力閥套	PRESSURE VALVE SLEEVE	1	
103	B050803110	壓力閥桿	VALVE ROD	1	
103-1	BG10110015010	O形環	O-RING	3	
104	B051403001	彈簧下座組	SPRING SEAT ASSY	1	
105	BJ40301000	調壓彈簧	PRESSURE REGULATING SPRING	1	
106	B051303110	彈簧上座	SPRING SEAT (UPPER)	1	
107	BS14108019200	圓頭螺絲	SCREW	2	
108	B050303000	調壓彈簧套	PRESSURE REGULATING PIPE	1	
*109	B053001001	調壓螺絲組	PRESSURE REGULATING SCREW ASSY	1	
*92 不屬於安全弁標準零件，須另外訂購。			* 92 is not a standard part, please order it as needed.		
*109 不屬於安全弁標準零件，須另外訂購。			*109 is not a standard part, please order it as needed.		
			2020.04V		

