




WL-3000F

零件表PARTS LIST WL-3000F

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
01	B010105010	曲軸箱	CRANKCASE	1		07	B010505000	柱塞銷	PISTON PIN	3	
02	B010205000	柱塞油封	PISTON OIL SEAL	3		08	B011005000	軸承油封蓋	BEARING COVER	2	
03	B010305000	腳座	CRANKCASE STAND	2		09	B010905000	曲軸油封	CRANKSHAFT OIL SEAL	2	
03-1	BS16212070500	內六角螺絲	HEX SCREW	2		10	B010705000	軸承	BEARING	2	
03-2	BS21212400	六角螺帽	NUT	2		11	BG11244130620	O形環	O-RING	4	
03-3	B012805000	腳套	SLIDE BASE	2		12	B010806010	曲軸	CRANKSHAFT	1	
03-4	BS11214050200	六角螺絲	SET BOLT	4		12-1	B012105000	曲軸鍵	CRANKSHAFT KEY	1	
03-5	BS32214300	彈簧華司	SPRING WASHER	4		13	BS11210020300	六角螺絲	SET BOLT	8	
03-6	BS31214200	平面華司	WASHER	4		13-1	BS32112300	彈簧華司	SPRING WASHER	8	
03-7	BS31116100	平面華司	WASHER	2		14	B011605010	曲軸箱後蓋	REAR COVER	1	
04	BS15214060300	雙頭牙螺絲	DOUBLE-END SCREW	4		15	B012201003	油鏡組	OIL WINDOW ASSY	1	
04-1	BS32214300	彈簧華司	SPRING WASHER	4		15-1	B012201020	油鏡	OIL WINDOW	1	
04-2	BS21214300	六角螺帽	NUT	4		15-2	BG10234028700	O形環	O-RING	1	
05	B013005001	柱塞組	PISTON ASSY	3		16	B012705000	擋油片	DAMPER PLATE	1	
05-1	B013105000	柱塞桿	PISTON	3		16-1	BS12205006200	大扁頭螺絲	SCREW	1	
05-2	B013205000	陶瓷柱塞套	CERAMIC PISTON SLEEVE	3		17	B011705000	後蓋迫緊	REAR COVER PACKING	1	
05-3	B013405000	柱塞套固定螺帽	SET NUT	3		18	BS14206020300	圓頭螺絲	SCREW	14	
05-3B	BG30253029	背托環	BACK-UP RING	3		18-1	BS32108300	彈簧華司	SPRING WASHER	14	
05-4	BG10219027100	O形環	O-RING	3		19	B011805000	排油螺絲	DRAINAGE SCREW	2	
05-5	B013305000	柱塞套固定螺絲	PISTON SCREW	3		19-1	BG10170022010	O形環	O-RING	2	
06A	B010605002	連桿	CONNECTING ROD ASSY	3		21	B020106010	汽缸	CYLINDER	1	
06	N/A	連桿	CONNECTING ROD	3		22	BJ60501010	V迫緊彈簧	SPRING	3	
06-1	B014105000	連桿軸套	CONNECTING ROD SLEEVE	6		23	B020205000	V迫緊底座	V-PACKING SEAT	3	
06-2	BS11208040500	六角螺絲	SET BOLT	6		24	B020305000	V迫緊(氟素)	V-PACKING (F.P.M.)	3	
06-3	BS32110500	彈簧華司	SPRING WASHER	6		24-1	B020305010	V迫緊(布皮氟素)	V-PACKING (F.P.M. FABRIC)	6	
06-4	BS31208503	平面華司	WASHER	6		25	B020505000	調整環	ADJUSTING RING	3	

零件表PARTS LIST WL-3000F

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
26	B021005000	防水油封	WATERPROOF OIL SEAL	3		41	B031105000	壓力錶	PRESSURE GAUGE	1	
27	BG10636068420	O形環	O-RING	3		*50	B060006002	自動洩壓總成	UNLOADING VALVE ASSY	1	
28	B022005010	油封固定片	SET PLATE	2		65	B030406000	空氣室	AIR CHAMBER	1	
29	BS11210015300	六角螺絲	SET BOLT	6		66	B011905000	加油蓋	OIL INLET COVER	1	
29-1	BS32112300	彈簧華司	SPRING WASHER	6		66-1	B012005000	加油蓋墊片	GASKET	1	
31	B011205010	柱塞中間皮	WATERPROOF RING	3		67	B100519050	圓內塞頭 1/4"	PLUG 1/4"	3	
32	BS15212067300	雙頭牙螺絲	DOUBLE-END SCREW	4		68	B011105000	曲軸蓋	CRANKSHAFT COVER	1	
32-1	BS32212300	彈簧華司	SPRING WASHER	6		69	BS14206012300	圓頭螺絲	SCREW	4	
32-2	BS21212300	六角螺帽	NUT	6		69-1	BS32108300	彈簧華司	SPRING WASHER	4	
33	BS15212091300	雙頭牙螺絲	DOUBLE-END SCREW	2		93	B013805000	皮帶輪固定環	SET RING	1	
34	B040006002	活門組	VALVE ASSY	6		96	BS11212025300	六角螺絲	SET BOLT	1	
34-1	B040305000	活門帽	VALVE CAGE	6		96-1	B013905000	皮帶輪保護墊圈	PROTECTING GASKET	1	
34-2	B040605000	活門環	VALVE RING	6		ACC.	B160106001	配件組 (含調壓螺絲組)	ACCESSORY BOX W/ KNOB ASSY	1	
34-3	BJ20501000	活門彈簧	VALVE SPRING	6		ACC.	B150406000	吸水螺帽	SUCTION NUT	1	
34-4	B040105000	活門塞	VALVE PLUG	6		ACC.	B150506000	吸水管申目	SUCTION HOSE SOCKET	1	
34-5	B040205020	活門座	VALVE SEAT	6		ACC.	BG10600066030	吸水管申目O形環	SUCTION HOSE SOCKET O-RING	1	
34-6	B040506000	活門塞座	VALVE PLUG BASE	6		ACC.	B150606000	過濾網申目	FILTER SOCKET	1	
34-7	B040405000	活門布皮	VALVE PACKING	6		ACC.	BG10480056020	網申目O形環	FILTER SOCKET O-RING	1	
35	B031406020	進水室	SUCTION CHAMBER	1		ACC.	B150905001	過濾網總成	FILTER ASSY	1	
36	BS15212153300	雙頭牙螺絲	DOUBLE-END SCREW	2		ACC.	B150706000	迴水螺帽	OVERFLOW HOSE WING NUT	1	
37	BS15212089300	雙頭牙螺絲	DOUBLE-END SCREW	4		ACC.	B150806000	迴水管申目	OVERFLOW HOSE SOCKET	1	
37-1	BS32212300	彈簧華司	SPRING WASHER	6		ACC.	BG10330039	迴水管申目O形環	OVERFLOW HOSE SOCKET O-RING	1	
37-2	BS21212300	六角螺帽	NUT	6		ACC.	BP22023440	皮帶輪 12B3*44*10*4	PULLEY 12B3*44*10*4	1	
39	B030206020	出水室	OUTLET CHAMBER	1		ACC.	BS11112032121	皮帶輪螺絲	PULLEY SET BOLT	1	
40	B031605000	球形閥 PT3/4	BALL COCK PT3/4	1		*50零件表及展開圖請參閱第4頁。			*50 parts list & diagram please refer to page 4.		
40-1	BK30107010	雙外牙接頭	CONNECTOR	1							

2019.10V

零件表PARTS LIST 自動洩壓總成 B060006002 / UNLOADING VALVE ASSEMBLY

WL-3000F系列用

[illegible]