




零件表PARTS LIST WH-1035F


圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
01	B010123000	曲軸箱	CRANKCASE	1		11	B012201020	油鏡	OIL WINDOW	1	
02	B010210001	柱塞油封	PISTON OIL SEAL	3		11-1	BG10234028700	O形環	O-RING	1	
03-1	1013323001	柱塞套固定螺絲	PISTON SCREW	3		12	B011823000	排油螺絲	DRAINAGE SCREW	1	
03-2	B015123003	止水墊片	GASKET	3		12-1	BG10130019	O形環	O-RING	1	
03-3	B013223400	柱塞套	CERAMIC PISTON SLEEVE	3		13	B011901014	加油蓋組	OIL INLET COVER ASSY	1	
03-4	B013511111	柱塞套透氣墊圈	GASKET	3		14	B020123400	汽缸	CYLINDER	1	
03-5	B013510020	柱塞套平墊圈	GASKET	3		14-1	BS16208070500	內六角螺絲	HEX SCREW	8	
03-6	B013123001	柱塞桿	PISTON ROD	3		14-2	BS33208400	安全華司	SAFETY WASHER	8	
04	B010523000	柱塞銷	PISTON PIN	3		15	B020323401	U迫緊	U-PACKING	3	
05A	B010623001	連桿組	CONNECTING ROD ASSY	3		16	B020323420	墊圈	GASKET	3	
05	N/A	連桿	CONNECTING ROD	3		17	B021023401	防水油封	WATERPROOF OIL SEAL	3	
05-1	BS11206030500	六角螺絲	SET BOLT	6		18	B021123400	迫緊上環	PACKING UPPER RING	3	
05-2	BS31206501	平面華司	WASHER	6		18-1	BG10314035040	O形環	O-RING	3	
05-3	B014311000	螺絲防鬆片	LOCK WASHER	3		19	B021323400	活門固定螺絲	VALVE BOLT W/O HOLE	6	
06	B010823400	曲軸	CRANKSHAFT	1		19-1	BG10220027020	O形環	O-RING	6	
06-1	B012109000	曲軸鍵	CRANKSHAFT KEY	1		20A	B040023401	活門組	VALVE ASSY	6	
07	B010710010	軸承	BEARING	2		22-1	B040323400	活門帽	VALVE CAGE	6	
08	B010910040	曲軸油封	CRANKSHAFT OIL SEAL	1		22-2	BJ22301000	活門彈簧	VALVE SPRING	6	
08-1	B010923100	全密曲軸油封	END COVER OIL SEAL	1		22-3	B040123400	活門塞	VALVE PLUG	6	
09	B011023000	曲軸油封蓋	CRANKSHAFT OIL SEAL COVER	1		22-4	B040223400	活門座	VALVE SEAT	6	
09-1	BS16206016501	內六角螺絲	HEX SCREW	8		21	BG10190024040	O形環	O-RING	6	
09-2	B011023100	全密曲軸油封蓋	END COVER OIL SEAL COVER	1		22	BS50004000	六角塞頭：PT1/8	PLUG PT1/8	1	
10	B011623000	曲軸箱後蓋	REAR COVER	1		23	B031210000	壓力錶接頭	PRESSURE GAUGE COUPLING	1	
10-1	BG11012106500	O形環	REAR COVER PACKING	1		24	B031110000	壓力錶	PRESSURE GAUGE	1	
10-2	BS16206016501	內六角螺絲	HEX SCREW	5		25	BS50024000	塞頭：PT3/4	PLUG PT3/4	1	
10-3	BS32206200	彈簧華司	SPRING WASHER	5		26	B071209000	出水接頭	OUTLET CONNECTOR	1	

零件表PARTS LIST WH-1035F

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
*27	B060019330	安全弁	SAFETY VALVE ASSY	1	
28	BS50016040	內六角油塞： PT1/2	PLUG PT1/2	1	
29	1S50012040	內六角油塞： PT3/8	PLUG PT3/8	1	
30	B071823402	90度迴水接頭	L-CONNECTOR	1	
31	B033002100	出水接頭	OUTLET CONNECTOR	1	
32	BK30307010	彎頭	ELBOW	1	
33	B010307000	腳座	CRANKCASE STAND	2	
33-1	BS11210015222	六角螺絲附華司	SET BOLT W/ WASHER	4	
ACC.	B150110003	吸水管組 3/4"*10尺	SUCTION HOSE ASSY 3/4"*10FT	1	
ACC.	B150201001	迴水管組 1/2"*9尺	OVERFLOW HOSE ASSY 1/2"*9FT	1	
ACC.	B150609120	過濾網申目	FILTER SOCKET	1	
ACC.	B150909110	過濾網	FILTER	1	
ACC.	BP20722240	皮帶輪 4-1/2B2*24(外銷用)	PULLEY (FOR EXPORT)	1	
ACC.	BS11112025121	皮帶輪螺絲(外銷用)	PULLEY SET BOLT (FOR EXPORT)	1	
*27零件表及展開圖請參閱第4頁。			*27 parts list & diagram please refer to page 4.		
			2020.05V		



零件表PARTS LIST 安全弁 B060019330 / SAFETY VALVE ASSEMBLY B060019330

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY
01	B060119350	安全弁本體	SAFETY VALVE BODY	1	15	B060619350	出水接頭	OUTLET CONNECTOR	1
02	B060919350	壓力閥座	PRESSURE VALVE SEAT	1	15-1	BG10210025040	O形環	O-RING	1
02-1	BG10150019040	O形環	O-RING	1					
03	B060819315	壓力閥	PRESSURE VALVE	1					
04	B062319350	安全弁接頭	SAFETY VALVE COUPLING	1					
04-1	BG10235028500	O形環	O-RING	1					
04-2	BG30168020010	背托環	BACKUP RING	2					
04-3	BG10160020040	O形環	O-RING	1					
05	B071109051	固定環	SET RING	1					
05-1	BS17106005300	無頭內六角螺絲	HEX SCREW	2					
06	B061019310	壓力閥桿	VALVE ROD	1					
06-1	BG10108014640	O形環	O-RING	1					
06-2	BG30111014300	背托環	BACKUP RING	2					
06-3	BG10068010640	O形環	O-RING	2					
06-4	BG30070010010	背托環	BACKUP RING	2					
07	B310115110	鋼珠	SST BALL	1					
08	B061419310	彈簧下座	SPRING SEAT	1					
09	BJ41901350	調壓彈簧	PRESSURE REGULATING SPRING	1					
10	B071311000	彈簧上座	SPRING SEAT (UPPER)	1					
11	B071709000	調壓螺帽	PRESSURE REGULATING KNOB	1					
12	B062619317	出水閥套	VALVE SLEEVE	1					
12-1	BG10190023040	O形環	O-RING	1					
13	B062619350	出水閥座套	VALVE SEAT SLEEVE	1					
13-1	BG10075014540	O形環	O-RING	1					
13-2	BG30150018	墊圈	GASKET	1					
14	BJ71901310	止水彈簧	SPRING	1					