




零件表PARTS LIST 45B2 型系列 / 45B2 SERIES

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
01	B010102300	曲軸箱 (紅)	CRANKCASE (RED)	1		20	B013102000	柱塞桿	PISTON	3	
	B010102310	曲軸箱 (藍)	CRANKCASE (BLUE)			21	B013202001	柱塞套	CERAMIC PISTON SLEEVE	3	
02	B011402000	防塵蓋	DUSTPROOF CAP	1		22	B013308000	柱塞套固定螺絲	PISTON SCREW	3	
03	BS11110019121	皮帶輪螺絲	PULLEY SET BOLT	1		23	B013508002	柱塞套平墊圈	GASKET	3	
04	BP11612240300	皮帶輪 9A2*24*5	PULLEY 9A2*24*5	1		24	BG10140018500	O形環	O-RING	3	
05	BS12106006200	大扁頭螺絲	SCREW	6		24-1	BG30156019	背托環	BACK-UP RING	3	
06	B011001000	曲軸油封蓋	CRANKSHAFT OIL SEAL COVER	1		25	B013408000	柱塞套固定螺帽	SET NUT	3	
07A	B011901014	加油蓋組	OIL INLET COVER ASSY (B)	1		19B	B013002003	陶瓷柱塞組 (G2)	CERAMIC PISTON ASSY (G2)	3	
08	B011702000	後蓋迫緊	REAR COVER PACKING	1		20B	B013102150	柱塞桿	PISTON ROD	3	
09	B011602521	曲軸箱後蓋 (紅)	REAR COVER (RED)	1		21B	B013202150	柱塞套	CERAMIC PISTON SLEEVE	3	
	B011602530	曲軸箱後蓋 (藍)	REAR COVER (BLUE)			22B	B013302150	柱塞套固定螺絲	PISTON SCREW	3	
10	BS12108016101	大扁頭螺絲	SCREW	5		23B	B015122153	止水墊片	GASKET	3	
11	B012201020	油鏡	OIL WINDOW	1		26	B010502110	柱塞銷	PISTON PIN	3	
11-1	BG10234028700	O形環	O-RING	1		27	B010402010	不鏽鋼柱塞	SST PISTON	3	
12A	B011801001	排油螺絲組	DRAINAGE SCREW ASSY	1		28	B010302000	腳座	CRANKCASE STAND	2	
12	B011801000	排油螺絲	DRAINAGE SCREW	1		29	BS11112016122	六角螺絲附華司	SET BOLT W/ WASHER	4	
12-1	BG10110015	O形環	O-RING	1		30	B012901110	汽缸銷	SET PIN	2	
13	B012101110	曲軸鍵	CRANKSHAFT KEY	1		31	B010202000	柱塞油封	PISTON OIL SEAL	3	
14	B010802110	曲軸	CRANKSHAFT	1		32	B011202010	柱塞中間皮	WATERPROOF RING	3	
15	B010602002	連桿	CONNECTING ROD	3		40	B020102000	汽缸	CYLINDER	1	
15-1	BS11206030500	六角螺絲	SET BOLT	6		41	BS11112025122	六角螺絲附華司	SET BOLT W/ WASHER	4	
15-2	BS32206501	彈簧華司	SPRING WASHER	6		42	BS15112070300	雙頭牙螺絲	DOUBLE-END SCREW	2	
16	B010702050	軸承	BEARING	2		43	BS21112100	六角螺帽	NUT	2	
17	B010902000	曲軸油封	CRANKSHAFT OIL SEAL	2		43-1	BS32112200	彈簧華司	SPRING WASHER	2	
18	B011101021	曲軸油封蓋 (套筒一體)	CRANKSHAFT OIL SEAL COVER (CONE)	1		44	B020801113	黃油杯	GREASE CUP	3	
19	B013002001	陶瓷柱塞組 (G1)	CERAMIC PISTON ASSY (G1)	3		45	B020202020	V迫緊底座	V-PACKING SEAT	3	


零件表PARTS LIST 45B2 型系列 / 45B2 SERIES

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
46	B020302160	V迫緊 (氟素)	V-PACKING (F.P.M.)	9		80	B030302000	出水室 (ASB2/ASBC2)	OUTLET CHAMBER (ASB2/ASBC2)	1	
	B020302170	V迫緊 (A120)	V-PACKING (A120)			81	BG10180024	O形環	O-RING	1	
	B020302150	V迫緊 (乙炔隆)	V-PACKING (UCL)			82	B030901110	三通球形閥	T-BALL VALVE	1	
	B020302140	V迫緊 (NBR)	V-PACKING (NBR)			83	B250001021	壓力錶 (橫)	PRESSURE GAUGE (HORIZONTAL)	1	
47	B020402011	黃油環 (POM)	GREASE RING (POM)	3		90	B030102000	出水室連結空氣室 (W-)	OUTLET & AIR CHAMBER (W-)	1	
	B020402110	黃油環 (銅)	GREASE RING (BRASS)			91	BG10140018500	O形環 (W-)	O-RING (W-)	1	
48	B020902000	V型油環	V-TYPE O-RING	3		92	B030801000	空氣室塞頭 (W-)	AIR CHAMBER PLUG (W-)	1	
49	B020502000	調整環	ADJUSTING RING	3		93	B030702000	出水塞頭 (W-)	PLUG (W-)	1	
50	B020702010	調整環固定夾	SET CLIP	3		94	BG10280034	O形環 (W-)	O-RING (W-)	1	
51/52	B031402031	進水室含銅接頭	SUCTION CHAMBER W/CONNECTOR	1		100	B030202000	出水室 (WL-)	OUTLET CHAMBER (WL-)	1	
51	B031402030	進水室	SUCTION CHAMBER	1		101	B031601110	球形閥 8.5mm	BALL COCK 8.5mm	2	
52	B032302110	進水室接頭	CONNECTOR	1		102	B030602001	防漏墊片 (WL-)	LEAK-PROOF GASKET (WL-)	1	
53	BS11112038122	六角螺絲附華司	SET BOLT W/ WASHER	2		103	B030502001	封口蝶頭 (WL-)	WING NUT (WL-)	1	
54	B040002031	活門組	VALVE ASSY	6		104	B031101000	壓力錶(圓)	PRESSURE GAUGE (ROUND)	1	
55	B040302030	活門帽	VALVE CAGE	6		105	B030402110	空氣室 (WL-)	AIR CHAMBER (WL-)	1	
55-1	B040502000	活門塞座	VALVE PLUG BASE	6		106	BG10219027100	O形環 (WL-)	O-RING (WL-)	1	
56	BJ20201002	活門彈簧	VALVE SPRING	6		107	B031502110	*進水口蓋(選配)	*SUCTION CHAMBER CAP (OPTIONAL)	1	
57	B040102020	活門塞	VALVE PLUG	6		ACC.	B150102001	吸水管組 1"*9 尺	SUCTION HOSE ASSY 1"*9FT	1	
58	B040202020	活門座	VALVE SEAT	6		ACC.	B150201001	迴水管組 1/2"*9尺	OVERFLOW HOSE ASSY 1/2"*9FT	1	
59	B040402000	活門皮	VALVE PACKING	6		ACC.	B150602110	過濾網申目	FILTER SOCKET	1	
*60A	B050002311	自動洩壓總成(G2)	UNLOADING VALVE (G2)	1		ACC.	B150901110	過濾網	FILTER	1	
	B050002316	自動洩壓總成(G3)	UNLOADING VALVE (G3)			*60A(G2)零件表及展開圖請參閱第5頁。			*60A(G2) parts list & diagram please refer to page 5.		
61-1	BS13110047122	六角十字螺絲附華司	SET BOLT W/ WASHER	2		*60A(G3)零件表及展開圖請參閱第7頁。			*60A(G3) parts list & diagram please refer to page 7.		
*70A	B050001004	安全弁(不含調壓螺絲組)(G2)	SAFETY VALVE(W/O KNOB) (G2)	1		*70A(G2)零件表及展開圖請參閱第4頁。			*70A(G2) parts list & diagram please refer to page 4.		
	B050001006	安全弁(G3)	SAFETY VALVE (G3)			*70A(G3)零件表及展開圖請參閱第6頁。			*70A(G3) parts list & diagram please refer to page 6.		
79A	B053001001	調壓螺絲組	PRESSURE REGULATING SCREW ASSY	1					2025.05V		

零件表PARTS LIST 安全弁 B050001004 (G2) / SAFETY VALVE ASSEMBLY (G2)

25B/45B2/520系列用

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
*71-1	BS11110025122	六角螺絲附華司	SET BOLT W/ WASHER	2	
*79A	B053001001	調壓螺絲組	PRESSURE REGULATING SCREW ASSY	1	
151	B050101031	迴水座	OVERFLOW CHAMBER	1	
152	B050901000	壓力閥	PRESSURE VALVE	1	
153	B051001000	壓力閥座	VALVE SEAT	1	
154	BG20250030	方形環	SQUARE RING	1	
156	B050601110	調壓把手	PRESSURE REGULATING HANDLE	1	
157	BS12108013100	大扁頭螺絲	SCREW	2	
158	B050701000	伸縮套皮	COMPRESSION PACKING	1	
159	B051201000	閥桿保持環	MAINTAINING RING	1	
160	B050801110	壓力閥桿	VALVE ROD	1	
161	B051401001	彈簧下座組	SPRING SEAT ASSY	1	
162	BJ40101000	調壓彈簧	PRESSURE REGULATING SPRING	1	
163	B051301000	彈簧上座	SPRING SEAT (UPPER)	1	
164	BS12108019101	大扁頭螺絲	SCREW	2	
165	B050301000	調壓彈簧套	PRESSURE REGULATING PIPE	1	
*71-1 不屬於安全弁標準零件，須另外訂購。			* 71-1 is not a standard part, please order it as needed.		
*79A 不屬於安全弁標準零件，須另外訂購。			* 79A is not a standard part, please order it as needed.		
			2021.09V		




零件表PARTS LIST 自動洩壓總成 B050002311 (G2) / UNLOADING VALVE ASSEMBLY (G2)

WL-45ASB2/530ASB2系列用

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
61	B050202000	洩壓汽缸套	UNLOADING VALVE CYLINDER	1	
*61-1	BS13110038122	六角十字螺絲附華司	SET BOLT W/ WASHER	2	
61-2	BG10220027010	O形環	O-RING	2	
62	BJ50201000	洩壓輔助彈簧	AUXILIARY SPRING	1	
63A	B052201001	柱塞活門組	PISTON VALVE ASSY	1	
63-1	B052201000	柱塞活門體	PISTON VALVE BODY	1	
63-2	BS18105016300	圓頭自攻螺絲	SCREW	1	
63-3	B052401000	閥塞頭	VALVE PLUG	1	
63-4	BG10080012010	O形環	O-RING	1	
63-5	B052501000	閥塞座	VALVE PLUG SEAT	1	
63-6	BJ30101000	球閥固定彈簧	SPRING	1	
63-7	B052301000	彈簧底座	SPRING SEAT	1	
63-8	B052601000	C扣環	C-CLIP	1	
64	BG20250030	方形環	SQUARE RING	1	
65	B052101110	壓力閥輔助片	AUXILIARY PLATE	1	
66	B051001000	壓力閥座	VALVE SEAT	1	
67	B050901000	壓力閥	PRESSURE VALVE	1	
68	B050801120	壓力閥桿	VALVE ROD	1	
69	B051901000	消音片	DAMPER PLATE	1	
70	B050501000	迴水座	OVERFLOW CHAMBER	1	
70-1	B051801110	迴水接頭	OVERFLOW COUPLING	1	
70-2	BS14108025122	圓頭螺絲附華司	SCREW & WASHER	4	
71	B050701020	伸縮套皮	COMPRESSION PACKING	1	
71-1	B051101010	平墊圈	WASHER	1	
72	B052001110	固定環	SET RING	1	
73	B051401110	彈簧下座(有牙)	SPRING SEAT	1	


圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
74	BJ40101000	調壓彈簧	PRESSURE REGULATING SPRING	1	
75	B051301000	彈簧上座	SPRING SEAT (UPPER)	1	
76	B050401000	調壓彈簧套	PRESSURE REGULATING PIPE	1	
*79A	B053001001	調壓螺絲組	PRESSURE REGULATING SCREW ASSY	1	
84	B031601110	球形閥 8.5mm	BALL COCK 8.5mm	2	
*61-1 不屬於自動洩壓總成標準零件，須另外訂購。			* 61-1 is not a standard part, please order it as needed.		
*79A 不屬於自動洩壓總成標準零件，須另外訂購。			* 79A is not a standard part, please order it as needed.		
			2024.01V		



零件表PARTS LIST 安全弁 B050001006 (G3) / SAFETY VALVE ASSEMBLY (G3)


25B/45B2/520系列用

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
71	B050101031	迴水座	OVERFLOW CHAMBER	1	
*71-1	BS11110025122	六角螺絲附華司	SET BOLT W/ WASHER	2	
72	BG20250030	方形環	SQUARE RING	1	
73	B051001000	壓力閥座	VALVE SEAT	1	
74	B050901000	壓力閥	PRESSURE VALVE	1	
75	B050801110	壓力閥桿	VALVE ROD	1	
76	B050701000	伸縮套皮	COMPRESSION PACKING	1	
76-1	B051201000	閥桿保持環	MAINTAINING RING	1	
77	B051401001	彈簧下座組	SPRING SEAT ASSY	1	
77-2	B053601001	調壓墊片	SPACER	1	
78	BJ40101002	調壓彈簧	PRESSURE REGULATING SPRING	1	
79	B051301250	彈簧上座	SPRING SEAT (UPPER)	1	
80	B050301001	調壓彈簧套	PRESSURE REGULATING SPRING SLEEVE	1	
80-1	BS12108019101	大扁頭螺絲	SCREW	2	
81	B052001010	安全弁固定環	SET RING	1	
82	B053601000	調壓把手墊片	GASKET	1	
83	B053001011	調壓把手	PRESSURE REGULATING KNOB	1	
84	B050601110	調壓把手	PRESSURE REGULATING HANDLE	1	
84-1	BS12108013100	大扁頭螺絲	SCREW	2	
*71-1 不屬於安全弁標準零件，須另外訂購。			* 71-1 is not a standard part, please order it as needed.		
			2024.01V		



零件表PARTS LIST 自動洩壓總成 B050002316 (G3) / UNLOADING VALVE ASSEMBLY (G3)

WL-45ASB2/530ASB2系列用

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
61	B050202000	洩壓汽缸套	UNLOADING VALVE CYLINDER	1		74	BJ40101002	調壓彈簧	PRESSURE REGULATING SPRING	1	
*61-1	BS13110038122	六角十字螺絲附華司	SET BOLT W/ WASHER	2		75	B051301250	彈簧上座	SPRING SEAT (UPPER)	1	
61-2	BG10220027010	O形環	O-RING	2		76	B050301002	調壓彈簧套	PRESSURE REGULATING PIPE	1	
62	BJ50201000	洩壓輔助彈簧	AUXILIARY SPRING	1		77	B052001010	安全弁固定環	SET RING	1	
63A	B052201001	柱塞活門組	PISTON VALVE ASSY	1		78	B053601000	調壓把手墊片	GASKET	1	
63-1	B052201000	柱塞活門體	PISTON VALVE BODY	1		79	B053001011	調壓把手	PRESSURE REGULATING KNOB	1	
63-2	BS18105016300	圓頭自攻螺絲	SCREW	1		84	B031601110	球形閥 8.5mm	BALL COCK 8.5mm	2	
63-3	B052401000	閥塞頭	VALVE PLUG	1		*61-1 不屬於自動洩壓總成標準零件，須另外訂購。			* 61-1 is not a standard part, please order it as needed.		
63-4	BG10080012010	O形環	O-RING	1					2024.01V		
63-5	B052501000	閥塞座	VALVE PLUG SEAT	1							
63-6	BJ30101000	球閥固定彈簧	SPRING	1							
63-7	B052301000	彈簧底座	SPRING SEAT	1							
63-8	B052601000	C扣環	C-CLIP	1							
64	BG20250030	方形環	SQUARE RING	1							
65	B052101110	壓力閥輔助片	AUXILIARY PLATE	1							
66	B051001000	壓力閥座	VALVE SEAT	1							
67	B050901000	壓力閥	PRESSURE VALVE	1							
68	B050801120	壓力閥桿	VALVE ROD	1							
69	B051901000	消音片	DAMPER PLATE	1							
70	B050501000	迴水座	OVERFLOW CHAMBER	1							
70-1	B051801110	迴水接頭	OVERFLOW COUPLING	1							
70-2	BS14108025122	圓頭螺絲附華司	SCREW & WASHER	4							
71	B050701020	伸縮套皮	COMPRESSION PACKING	1							
71-1	B051101010	平墊圈	WASHER	1							
72	B052001110	固定環	SET RING	1							
73	B051401110	彈簧下座(有牙)	SPRING SEAT	1							

B050002316 (G3)
適用機型 FOR:
WL-45ASB2 SERIES
WL-530ASB2 SERIES