




WH-10120

零件表PARTS LIST WH-10120

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
01	B010116310	曲軸箱	CRANKCASE	1		09	B010916010	曲軸油封	CRANKSHAFT OIL SEAL	2	
01-4	B012903000	汽缸銷	SET PIN	2		10	B011004000	曲軸油封蓋	CRANKSHAFT OIL SEAL COVER	2	
02	B010216000	柱塞油封	PISTON OIL SEAL	3		10B	B011104000	曲軸油封蓋 (套筒)	CRANKSHAFT OIL SEAL COVER (CONE)	1	
03	B010316000	調皮帶輪腳座 (左)	CRANKCASE STAND (LEFT)	1		11	BS11110013222	六角螺絲附華司	SET BOLT W/ WASHER	8	
	B010316001	調皮帶輪腳座 (右)	CRANKCASE STAND (RIGHT)	1		12	B011604312	曲軸箱後蓋	REAR COVER	1	
03-1	BS11116025200	六角螺絲	SET BOLT	4		12-1	B012201020	油鏡	OIL WINDOW	1	
	BS32116200	彈簧華司	SPRING WASHER	4		12-2	BG10234028700	O形環	O-RING	1	
04A	B013015001	柱塞組	PISTON ASSY	3		12-3	B011704001	後蓋迫緊	REAR COVER PACKING	1	
04-1	B013115000	柱塞桿	PISTON	3		12-4	BS12108016100	大扁頭螺絲	SCREW	7	
04-2	B013215010	柱塞套	CERAMIC PISTON SLEEVE	3		13	B011810000	排油螺絲	DRAINAGE SCREW	1	
04-3	B013404010	柱塞套固定螺帽	SET NUT	3		13-1	BG10106017700	O形環	O-RING	1	
04-4	B013315000	柱塞套固定螺絲	PISTON SCREW	3		14	B011901014	加油蓋組	OIL INLET COVER ASSY	1	
04-5	BG10237030700	O形環	O-RING	3		28	B011404000	防塵蓋	DUSTPROOF CAP	1	
04-6	B013504000	柱塞套平墊圈	GASKET	3		21	B020115000	汽缸	CYLINDER	1	
04-7	BG30241030	背托環	BACK-UP RING	3		21-1	BS15120063300	雙頭牙螺絲	DOUBLE-END SCREW	4	
05	B010515000	柱塞銷	PISTON PIN	3		21-2	BS32120300	彈簧華司	SPRING WASHER	4	
06A	B010615001	連桿組	CONNECTING ROD ASSY	3		21-3	BS21120300	六角螺帽	NUT	4	
06	N/A	連桿	CONNECTING ROD	3		21-4	BS15114076300	雙頭牙螺絲	DOUBLE-END SCREW	2	
06-1	BS11110044500	六角螺絲	SET BOLT	6		21-5	BS32114300	彈簧華司	SPRING WASHER	2	
06-2	BS31208503	平面華司	WASHER	6		21-6	BS21114300	六角螺帽	NUT	2	
06-3	B014315000	螺絲防鬆片	LOCK WASHER	3		22	B023415000	U迫緊套筒	BUSHING	3	
06-4	B014215000	引擎培林	ENGINE BEARING	3		23	B020315010	V迫緊	V-PACKING	3	
06-5	B014105000	連桿軸套	CONNECTING ROD SLEEVE	6		23-1	B020315000	V迫緊	V-PACKING	3	
07	B010704320	軸承	BEARING	2		24	B020415000	黃油環	GREASE RING	3	
08	B010816000	曲軸	CRANKSHAFT	1		25	B020515000	調整環	ADJUSTING RING	3	
08-1	B012115000	曲軸鍵	CRANKSHAFT KEY	1		25-1	BG10585063730	O形環	O-RING	3	

零件表PARTS LIST WH-10120

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
26	B021015000	防水油封 (農林)	WATERPROOF OIL SEAL	3		52	BK30410011	90度接頭	L-CONNECTOR	1	
26-1	BS41055010	C扣環	C-CLIP	3		*60A	B060015001	自動洩壓總成	UNLOADING VALVE ASSY	1	
26-2	B020315020	U迫緊	U-PACKING	3		71	B062406001	調壓螺絲組	PRESSURE REGULATING SCREW ASSY	1	
26-3	B024015000	U迫緊墊片	U-PACKING GASKET	3		73	BK30610010	雙外牙接頭	CONNECTOR	1	
30A	B040015001	進水活門組	INLET VALVE ASSY	3		97	BP22023360	皮帶輪 12B3*36*8	PULLEY 12B3*36*8	1	
30-1	B040815000	進水活門體	VALVE BODY	3		97-1	BS11112032121	六角螺絲	SET BOLT	1	
30-2	BG10540059030	O形環	O-RING	3		97-2	BS11112025122	六角螺絲附華司	SET BOLT W/ WASHER	1	
30-3	BG30542057800	背托環	BACK-UP RING	3		97-3	B013916000	皮帶輪保護墊圈	PROTECTING GASKET	1	
30-4	B040315000	活門帽	VALVE CAGE	3		98-1	BS11112064300	六角螺絲	SET BOLT	2	
30-5	BJ20402000	活門彈簧	VALVE SPRING	3		98-2	BS21112300	六角螺帽	NUT	2	
30-6	B040104010	活門塞	VALVE PLUG	3		98-3	BS31210300	平面華司	WASHER	2	
30-7	B040215000	活門座	VALVE SEAT	3		98-4	B101901000	U型架螺絲固定套	SET SLEEVE	2	
30-8	BG10430051030	O形環	O-RING	3		ACC.	B150404110	吸水螺帽	SUCTION NUT	1	
30-9	BG30433049900	背托環	BACK-UP RING	3		ACC.	B150504120	吸水管申目	SUCTION HOSE SOCKET	1	
31	B021915000	進水活門固定片 (無孔)	SET PLATE W/O HOLE	3		ACC.	BG20420052030	方形環 (吸水管申目)	SQUARE RING (SUCTION SOCKET)	1	
31-1	BG10540059030	O形環	O-RING	3		ACC.	B150706000	迴水螺帽	OVERFLOW HOSE WING NUT	1	
31-2	BS15112039300	雙頭牙螺絲	DOUBLE-END SCREW	24		ACC.	B150806000	迴水管申目	OVERFLOW HOSE SOCKET	1	
31-3	BS32112300	彈簧華司	SPRING WASHER	24		ACC.	BG10330039	O形環 (迴水管申目)	O-RING (OVERFLOW SOCKET)	1	
31-4	BS21112301	進出水蓋固定螺帽	NUT	24		ACC.	B150904001	過濾網總成	FILTER ASSY	1	
31-5	BS31112306	平面華司	WASHER	24		ACC.	B150604000	過濾網申目	FILTER SOCKET	1	
32	B021715000	進水接頭	INLET CONNECTOR	1		ACC.	BG10480056020	O形環 (過濾網申目)	O-RING (FILTER SOCKET)	1	
33A	B040015011	出水活門組	OUTLET VALVE ASSY	3							
33-1	B021815000	出水活門固定片	SET PLATE	3							
33-2	BG30456051900	背托環	BACK-UP RING	3							
33-3	BG10430051030	O形環	O-RING	3		*60A零件表及展開圖請參閱第4頁。			*60A parts list & diagram please refer to page 4.		
51	B031109000	壓力錶	PRESSURE GAUGE	1					2021.03V		

零件表PARTS LIST 自動洩壓總成 B060015001 / UNLOADING VALVE ASSEMBLY

WH-10120用

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
61	B060106000	液壓缸	RELIEF VALVE CYLINDER	1	
61-2	BG10410046	O形環	O-RING	1	
62	BS11112019300	六角螺絲	SET BOLT	1	
63	B060814000	壓力閥	PRESSURE VALVE	1	
64	BG10140018520	O形環	O-RING	2	
65	B060714000	柱塞軸	PISTON SHAFT	1	
66	BG10320037840	O形環	O-RING	2	
67	BG30326037	背托環	BACK-UP RING	2	
68	B061406000	彈簧下座	SPRING SEAT	1	
69	BJ40501000	調壓彈簧	PRESSURE REGULATING SPRING	1	
70	B061306000	彈簧上座	SPRING SEAT (UPPER)	1	
*71	B062406001	調壓螺絲組	PRESSURE REGULATING SCREW	1	
72	B060206000	調壓彈簧套	PRESSURE REGULATING PIPE	1	
72-1	BS16108016300	內六角螺絲	SCREW	4	
72-2	BS32108300	彈簧華司	SPRING WASHER	4	
*71 不屬於標準零件，須另外訂購。			* 71 is not a standard part, please order it as needed.		
			2020.03V		

