



WH-12140  
WH-12170

零件表PARTS LIST WH-12140 / WH-12170

圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY
01	B010119320	曲軸箱	CRANKCASE	1	04-5	B013519001	柱塞套平墊圈	GASKET	3
01-1	B180106010	指示黏標	ARROW LABEL	2	04-6	B013419000	柱塞套固定螺帽	SET NUT	3
01-2	B012919000	汽缸銷	SET PIN	2	04-7	BG10110015020	O形環	O-RING	3
01-3	B100519050	圓內塞頭 1/4"	PLUG 1/4"	3	04-8	BG30123015900	背托環	BACK-UP RING	3
01-4	BS50016010	塞頭：PT1/2	PLUG PT1/2	1	05	B010519000	柱塞銷	PISTON PIN	3
02	B010219010	柱塞油封	PISTON OIL SEAL	3	06A	B010619001	連桿組	CONNECTING ROD ASSY	3
02-1	B014419000	柱塞油封套(WH-12140)	PISTON OIL SEAL SLEEVE (WH-12140)	3	06	N/A	連桿	CONNECTING ROD	3
	B014419210	柱塞油封套(WH-12170)	PISTON OIL SEAL SLEEVE (WH-12170)		06-1	B014119000	連桿軸套	CONNECTING ROD SLEEVE	6
02-2	BG10430049050	O形環	O-RING	3	06-2	B014319000	螺絲防鬆片	LOCK WASHER	3
02-3	B014519000	柱塞油封墊圈	GASKET	3	06-3	BS31210500	平面華司	WASHER	6
03	B010319000	腳座	CRANKCASE STAND	2	06-4	BS11210055500	六角螺絲	SET BOLT	6
03-1	BS15214057300	雙頭牙螺絲	DOUBLE-END SCREW	4	06-5	B014219000	引擎培林	ENGINE BEARING	3
03-2	BS31214200	平面華司	WASHER	4	07	B010719000	軸承	BEARING	2
03-3	BS32214300	彈簧華司	SPRING WASHER	4	08	B010819001	曲軸	CRANKSHAFT	1
03-4	BS21214300	六角螺帽	NUT	4	08-1	B012119000	曲軸鍵	CRANKSHAFT KEY	1
03-5	BS11212100300	六角螺絲	SET BOLT	2	08-2	B013905000	皮帶輪保護墊圈	PROTECTING GASKET	1
03-6	BS21212300	六角螺帽	NUT	2	08-3	BS32212300	彈簧華司	SPRING WASHER	1
03-7	BS31212201	平面華司	WASHER	2	08-4	BS11212025300	六角螺絲	SET BOLT	1
04A	B013019001	柱塞組 (WH-12140)	PISTON ASSY (WH-12140)	3	09	B010919010	曲軸油封	CRANKSHAFT OIL SEAL	2
	B013019010	柱塞組 (WH-12170)	PISTON ASSY (WH-12170)		10	B011019320	軸承油封蓋	BEARING OIL SEAL COVER	2
04-1	B013119010	柱塞桿	PLUNGER	3	10-1	BG11144120630	O形環	O-RING	2
04-2	B013519010	柱塞套透氣墊圈 (WH-12140)	GASKET (WH-12140)	3	10-2	B012619000	軸承蓋平墊圈	SHIM	4
	B013519210	柱塞套透氣墊圈 (WH-12170)	GASKET (WH-12170)		10-3	BS16208025300	內六角螺絲	HEX SCREW	8
04-3	B013219000	柱塞套 (WH-12140)	CERAMIC PISTON SLEEVE (WH-12140)	3	10-4	BS32208300	彈簧華司 (WH-12140)	SPRING WASHER (WH-12140)	8
	B013219210	柱塞套 (WH-12170)	CERAMIC PISTON SLEEVE (WH-12170)			BS32110300	彈簧華司 (WH-12170)	SPRING WASHER (WH-12170)	
04-4	B013319000	柱塞套固定螺絲	PISTON SCREW	3	10-5	BS31208306	平面華司	WASHER	8

零件表PARTS LIST WH-12140 / WH-12170

圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY
11	B011119310	曲軸蓋	CRANKSHAFT COVER	1	*19	B023819110	潤滑棉固定套 (WH-12140)	GASKET (WH-12140)	3
11-1	BS16206016300	內六角螺絲	HEX SCREW	4		B023819111	潤滑棉固定套 (WH-12170)	GASKET (WH-12170)	
11-2	BS32206300	彈簧華司 (WH-12140)	SPRING WASHER (WH-12140)	4	21	B031419010	汽缸後座 (WH-12140)	SUCTION CHAMBER (WH-12140)	1
	BS32108300	彈簧華司 (WH-12170)	SPRING WASHER (WH-12170)			B031419110	汽缸後座 (WH-12170)	SUCTION CHAMBER (WH-12170)	
11-3	BS31206302	平面華司	WASHER	4	21-1	BG10320040	O形環 (WH-12140)	O-RING (WH-12140)	3
12	B011619320	曲軸箱後蓋	REAR COVER	1		BG10345041500	O形環 (WH-12170)	O-RING (WH-12170)	
12-1	B011719000	後蓋迫緊	REAR COVER PACKING	1	21-2	BS16214040300	內六角螺絲	HEX SCREW	4
12-2	BS16208025300	內六角螺絲	HEX SCREW	8	21-3	BS16212040300	內六角螺絲	HEX SCREW	2
12-3	BS32208300	彈簧華司 (WH-12140)	SPRING WASHER (WH-12140)	8	21-4	BS16212100300	內六角螺絲	HEX SCREW	2
	BS32110300	彈簧華司 (WH-12170)	SPRING WASHER (WH-12170)		21-5	B100519030	圓內塞頭 1-1/2"	PLUG 1-1/2"	2
12-4	BS31208306	平面華司	WASHER	8	22	B021019000	防水油封 (WH-12140)	WATERPROOF OIL SEAL (WH-12140)	3
13	B012219050	油量指示螺絲	SCREW	1		B021019210	防水油封 (WH-12170)	WATERPROOF OIL SEAL (WH-12170)	
13-2	B012219000	油量指示棒	OIL POINTER	1	22-1	B024019000	防水油封墊圈 (WH-12140)	GASKET (WH-12140)	3
14	B011810000	排油螺絲	DRAINAGE SCREW	1	23	B021219020	V迫緊套 (WH-12140)	V-PACKING COLLAR (WH-12140)	3
14-1	BG10106017700	O形環	O-RING	1		B021219210	V迫緊套 (WH-12170)	V-PACKING COLLAR (WH-12170)	
15	B011905000	加油蓋	OIL INLET COVER	1	24	B020319040	V迫緊 (WH-12140)	V-PACKING (WH-12140)	6
15-1	B012719010	擋油片	DAMPER PLATE	1		B020319210	V迫緊 (WH-12170)	V-PACKING (WH-12170)	
15-2	B014619310	擋油盒	OIL PAN	1	25	B020219000	V迫緊底座 (WH-12140)	V-PACKING SEAT (WH-12140)	3
15-3	B012005000	加油蓋方形環	GASKET	1		B020219210	V迫緊底座 (WH-12170)	V-PACKING SEAT (WH-12170)	
16	BS81212100	環首螺栓	SCREW	1	26	BJ61901021	V迫緊彈簧 (WH-12140)	V-PACKING SPRING (WH-12140)	3
16-1	BS31212201	平面華司	WASHER	1		BJ61901211	V迫緊彈簧 (WH-12170)	V-PACKING SPRING (WH-12170)	
*17	B014619000	油盒 (選配)	OIL PAN (Optional)	1	27	B021119000	迫緊上環 (WH-12140)	PACKING UPPER RING (WH-12140)	3
*17-1	BS31206310	平面華司 (選配)	WASHER (Optional)	2		B021119210	迫緊上環 (WH-12170)	PACKING UPPER RING (WH-12170)	
*17-2	BS16206016300	內六角螺絲 (選配)	HEX SCREW (Optional)	2	27-1	BG10472054230	O形環 (WH-12140)	O-RING (WH-12140)	6
*18	B011319010	潤滑棉 (WH-12140選配)	FELT COLLAR (WH-12140 Optional)	3		BG10504057400	O形環 (WH-12170)	O-RING (WH-12170)	
	B011319210	潤滑棉 (WH-12170選配)	FELT COLLAR (WH-12170 Optional)		27-2	BG30490054810	背托環 (WH-12140)	BACK-UP RING (WH-12140)	6

零件表PARTS LIST WH-12140 / WH-12170

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
27-2	BG30515056800	背托環 (WH-12170)	BACK-UP RING (WH-12170)	6	
28	B020119010	汽缸前座 (WH-12140)	CYLINDER (WH-12140)	1	
	B020119110	汽缸前座 (WH-12170)	CYLINDER (WH-12170)		
28-1	BS16212070300	內六角螺絲	HEX SCREW	8	
28-2	B100519040	圓內塞頭 1"	PLUG 1"	2	
29A	B040019002	活門組 (WH-12140)	VALVE ASSY (WH-12140)	6	
	B040019011	活門組 (WH-12170)	VALVE ASSY (WH-12170)		
29-1	B040819000	活門套	VALVE CAGE	6	
29-2	B040319010	活門帽	VALVE CAGE	6	
29-3	BJ21901001	活門彈簧	VALVE SPRING	6	
29-4	B040119000	活門塞	VALVE PLUG	6	
29-5	B040219000	活門座 (WH-12140)	VALVE SEAT (WH-12140)	6	
	B040219210	活門座 (WH-12170)	VALVE SEAT (WH-12170)		
29-6	BG10280032030	O形環 (WH-12140)	O-RING (WH-12140)	6	
	BG10315035500	O形環 (WH-12140)	O-RING (WH-12140)		
29-7	BG30290031810	背托環 (WH-12140)	BACK-UP RING (WH-12140)	6	
	BG30320034800	背托環 (WH-12170)	BACK-UP RING (WH-12170)		
30	B021319020	活門固定螺絲	SET BOLT	6	
30-1	BG30400045810	背托環	BACK-UP RING	6	
30-2	BG10387045730	O形環	O-RING	6	
31	BJ21901211	活門輔助彈簧	SPRING	6	
*32	B021719001	進水接頭 (WH-12140)	INLET COUPLING (WH-12140)	1	
	B021719001	進水接頭 (WH-12170選配)	INLET COUPLING (WH-12170 Optional)		
*選配的安全弁零件表及展開圖請參閱第5頁。			*Optional safety valve parts list & diagram please refer to page 5.		
			2022.07V.		



