



WH-1540

零件表PARTS LIST WH-1540

圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY
01	B010118000	曲軸箱	CRANKCASE	1	08-3	BS32110200	彈簧華司	SPRING WASHER	1
01-3	B012903000	汽缸銷	SET PIN	2	08-4	BS31110202	平面華司	WASHER	1
02	B010218000	柱塞油封	PISTON OIL SEAL	3	09	B010918010	曲軸油封	CRANKSHAFT OIL SEAL	2
03	B010303000	腳座	CRANKCASE STAND	2	10	B011003110	曲軸油封蓋	CRANKSHAFT OIL SEAL COVER	2
03-1	BS11112016122	六角螺絲附華司	SET BOLT W/ WASHER	4	10-1	BS12108010100	大扁頭螺絲	SCREW	8
04A	B013018001	柱塞組	PISTON ASSY	3	12	B011603311	曲軸箱後蓋	REAR COVER	1
04-1	B013118000	柱塞桿	PISTON ROD	3	12A	B012201003	油鏡組	OIL WINDOW ASSY	1
04-2	B013518000	柱塞套透氣墊圈	GASKET	3	12-1	B012201020	油鏡	OIL WINDOW	1
04-3	B013216000	柱塞套	CERAMIC PISTON SLEEVE	3	12-2	BG10234028700	O形環	O-RING	1
04-4	B013416000	柱塞套固定螺帽	SET NUT	3	12-3	B011703000	後蓋迫緊	REAR COVER PACKING	1
04-5	B013316000	柱塞套固定螺絲	PISTON SCREW	3	12-4	BS12108016100	大扁頭螺絲	SCREW	7
04-6	BG10110015020	O形環	O-RIN	3	13	B011810000	排油螺絲	OIL DRAINAGE SCREW	1
04-7	BG30112014900	背托環	BACK-UP RING	3	13-1	BG10106017700	O形環	O-RING	1
04-8	B013516000	柱塞套平墊圈	GASKE	3	14A	B011901014	加油蓋組	OIL INLET COVER ASSY	1
05	B010503110	柱塞銷	PISTON PIN	3	15	B011102111	曲軸油封蓋(套筒)	CRANKSHAFT OIL SEAL COVER (CONE)	1
06A	B010618002	連桿組	CONNECTING ROD ASSY	3	15-1	BG10280030	O形環	O-RING	1
06	N/A	連桿	CONNECTING ROD	3	21	B020118000	汽缸	CYLINDER	1
06-1	BS11208035500	六角螺絲	SET BOLT	6	21-1	BS15116060300	雙頭牙螺絲	DOUBLE-END SCREW	4
06-2	BS31208500	平面華司	WASHER	6	21-2	BS32116300	彈簧華司	SPRING WASHER	4
06-3	B014318000	螺絲防鬆片	LOCK WASHER	3	21-3	BS21116300	六角螺帽	NUT	4
06-4	B014218000	引擎培林	ENGINE BEARING	3	21-4	BS16110038300	內六角螺絲	HEX SCREW	2
06-5	BS31208503	平面華司	WASHER	6	21-5	BS32110300	彈簧華司	SPRING WASHER	2
07	B010703320	軸承	BEARING	2	22	B023418000	U迫緊套筒	BUSHING	3
08	B010818010	曲軸	CRANKSHAFT	1	23	B020308030	U迫緊	U-PACKING	6
08-1	B012109000	曲軸鍵	CRANKSHAFT KEY	1	23-1	B023708000	U迫緊輔助圈	AUXILIARY RING	3
08-2	BS11110019100	六角螺絲	SET BOLT	1	24	B021218000	迫緊中間環	SPACER RING	3

零件表PARTS LIST WH-1540

圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY
25	B020518000	調整環	ADJUSTING RING	3	97	BP21822240100	皮帶輪 10B2*24*8	PULLEY 10B2*24*8	1
25-1	BG10400046	O形環	O-RING	3	97-1	BS11112032121	六角螺絲	SET BOLT	1
26	B021008000	防水油封	WATERPROOF OIL SEAL	3	ACC.	B150103001	吸水管組 1-1/4"*10尺	SUCTION HOSE ASSY 1-1/4"*10 FT	1
28	B011403000	防塵蓋	DUSTPROOF CAP	1	ACC.	B150101001	迴水管組 3/4"*9尺	SUCTION HOSE ASSY 3/4"*9 FT	1
30A	B040018001	進水活門組	INLET VALVE ASSY	3	ACC.	B150603110	過濾網申目	FILTER SOCKET	1
30-1	B040818000	進水活門體	INLET VALVE BODY	3	ACC.	B150903110	過濾網	FILTER	1
30-2	BG10360043040	O形環	O-RING	3					
30-3	BG30360041900	背托環	BACK-UP RING	3					
30-4	B040303010	活門帽	VALVE CAGE	3					
30-5	BJ20304000	活門彈簧	VALVE SPRING	3					
30-6	B040116000	活門塞	VALVE PLUG	3					
30-7	B040216000	活門座	VALVE SEAT	3					
30-8	BG10320036040	O形環	O-RING	3					
30-9	BG30328035900	背托環	BACK-UP RING	3					
31	B021318010	進水活門固定螺絲(無孔)	VALVE BOLT W/O HOLE	3					
31-1	BG10400046	O形環	O-RING	3					
32	B021716000	進水接頭	INLET CONNECTOR	1					
33A	B040018011	出水活門組	OUTLET VALVE ASSY	3					
33-1	B021318000	出水活門固定螺絲	VALVE BOLT	3					
33-2	BG30369042900	背托環	BACK-UP RING	3					
33-3	BG10360043040	O形環	O-RING	3					
51	B031109000	壓力錶	PRESSURE GAUGE	1					
52	B031218010	壓力錶接頭	PRESSURE GAUGE COUPLING	1					
61-2	B023518000	安全弁接頭	UNLOADING VALVE COUPLING	1					
<b>60A</b>	<b>B070018001</b>	<b>自動洩壓總成</b>	<b>UNLOADING VALVE ASSY</b>	<b>1</b>	*60A 零件表及展開圖請參閱第4頁。			*60A spare parts list & diagram please refer to page 4.	
67-6	B071818000	迴水接頭	OVERFLOW COUPLING	1				2020.03V	



零件表PARTS LIST 自動洩壓總成 B070018001 / UNLOADING VALVE ASSEMBLY

圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY
61	B070116000	洩壓汽缸套	UNLOADING VALVE CYLINDER	1
61-1	B071916000	柱塞活門套	PISTON VALVE COLLAR	1
62A	B070616001	柱塞活門組	PISTON VALVE ASSY	1
62	B070616000	柱塞活門體	PISTON VALVE BODY	1
62-1	BG30291034	背托環	BACK-UP RING	2
62-2	BG10280034	O形環	O-RING	2
62-3	B072016000	閥塞頭	VALVE PLUG	1
62-4	BJ30301010	球閥固定彈簧	SPRING	1
62-5	B052303110	彈簧底座	SPRING SEAT	1
62-6	B052603000	C扣環	C-CLIP	1
63	B070416000	閥座套	VALVE SEAT COLLAR	1
63-1	BG10320037820	O形環	O-RING	1
64	B070316000	陶瓷球閥	CERAMIC BALL VALVE	1
65	B070518000	壓力閥桿	VALVE ROD	1
65-1	BG10110015020	O形環	O-RING	2
65-2	BG30114014900	背托環	BACK-UP RING	1
66	B051903000	消音片	DAMPER PLATE	1
67	B070218000	迴水座	OVERFLOW CHAMBER	1
67-1	BG10320037820	O形環	O-RING	1
67-2	BS32110300	彈簧華司	SPRING WASHER	4
67-3	BS16110019300	內六角螺絲	HEX SCREW	4
67-4	B320113000	固定環	SET RING	1
67-5	BS17106005300	無頭內六角螺絲	SCREW	2
68	B071409000	彈簧下座	SPRING SEAT	1
69	BJ41601000	調壓彈簧	PRESSURE REGULATING SPRING	1
70	B071316000	彈簧上座	SPRING SEAT (UPPER)	1

