







零件表PARTS LIST WH-1711M1 / WH-2112M1 / WH-2512M1

圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY
19	B110250503	開關箱本體	CONTROL BOX	1	24	B102950520	電源線固定片 (WH-1711M1)	SET PLATE (WH-1711M1)	1
19-1	B130250120	接觸器	CONTACTOR	1		B102950530	電源線固定片 (WH-2112M/2512M1)	SET PLATE (WH-2112M1/2512M1)	
19-2	BS18204016201	扁頭自攻螺絲	SCREW	4	24-1	BS12205015300	大扁頭螺絲	SCREW	2
19-3	B130655010	漏電開關	CIRCUIT BREAKER	1	25	B100850500	外箱固定片	SET PLATE	2
19-4	BS18204025100	圓頭自攻螺絲	SCREW	2	25-1	BS18105016300	圓頭自攻螺絲	SCREW	4
19-5A	B130450020	計時器底座	TIMER BASE PF085AE	1	26	B100650500	電木螺絲	COVER SET SCREW	2
19-6A	BS18203020201	圓頭自攻螺絲	SCREW	2	26-1	BS22205300	防鬆螺帽	NUT	2
*19-7A	<b>B130350010</b>	<b>計時器</b>	<b>TIMER</b>	<b>1</b>	28	B081450500	推把	HANDLE	1
19-8	B130908020	熱動電驛	THERMAL RELAY	1	29	B081650500	外箱	COVER	1
19-10	B130550500	電源開關	POWER SWITCH	1	ACC.	A030105000	噴槍+噴嘴(WH-1711M1)	SPRAY GUN W/NOZZLE (WH-1711M1)	1
19-11A	B100569000	扣子塞	PLUG	1	ACC.	A030105001	噴槍+噴嘴(WH-2112M1/2512M1)	SPRAY GUN W/NOZZLE (WH-2112M1/2512M1)	1
19-14	B110565000	電源線固定夾	WIRE BINDER/NUT	2	ACC.	B150110003	吸水管組 3/4"*10尺	SUCTION HOSE ASSY 3/4"*10FT	1
19-17	B250304000	微動開關	MICRO SWITCH	1	ACC.	BC10101001	高壓管*10M + C1	HIGH PRESSURE HOSE*10M + C1	1
	B250305000	微動開關保護套	STARTER COVER	1					
20	BS12108025200	大扁頭螺絲	SCREW	3					
20-1	BG10160021020	O形環	O-RING	1					
20-2	BS34108200	外齒華司	WASHER	3					
21	B110350500	配線盒上蓋	CONTROL BOX COVER	1					
21-1	BS18204025100	圓頭自攻螺絲	SCREW	4					
21-2	BG10036007200	O形環	O-RING	4					
22	B101850500	微動開關固定片	SET PLATE	1					
22-1	BS12108010100	大扁頭螺絲	SCREW	2					
22-2	BS34108200	外齒華司	WASHER	2					
23	B250301000	固定片	SET PLATE	1					
23-1	BS14105032200	圓頭螺絲	SCREW	2					
23-2	BS31204200	平面華司	WASHER	2					

2020.08V.