



零件表PARTS LIST WH-2012E3

圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY
01	B080558003	收折台架	FRAME	1	06-4	BS33206400	安全華司	SAFETY WASHER	4
02	B080659000	輪軸	WHEEL SHAFT	1	07	B120553020	連軸器-泵浦	FLEXIBLE COUPLING (M)	1
02-1	BS11210065200	六角螺絲	HEX SCREW	2	07-1	B120453030	連軸器-引擎	FLEXIBLE COUPLING (F)	1
02-2	BS22210300	防鬆螺帽	LOCK NUT	2	07-2	B120353000	連軸器內襯	BUSHING	6
02-3	BS31210300	平面華司	WASHER	2	07-3	BS17112013500	無頭內六角螺絲	SCREW	4
03	B081057000	固定輪	WHEEL	2	08	B120258040	法蘭盤墊片	FLANGE BASE PLATE	1
03-1	BS70043000	開口銷	PIN	4	08-1	BS16208025500	內六角螺絲	SCREW	4
03-2	B081350000	車輪護蓋	WHEEL COVER	2	08-2	BS33208400	安全華司	SAFETY WASHER	4
03-3	B100150000	平面華司	WASHER	4	09	B100358001	引擎襯套	SPACER RING	1
04	B080958001	腳架	LEG	1	10	BA10055203	HONDA 引擎 5.5HP GX160T2	HONDA ENGINE 5.5HP GX160T2	1
04-1	BS11210025200	六角螺絲	HEX SCREW	2	10-1	BS11208040200	六角螺絲	SCREW	4
04-2	BS31210300	平面華司	WASHER	4	10-2	BS31208302	平面華司	WASHER	8
04-3	BS22210300	防鬆螺帽	LOCK NUT	2	10-3	BS22208300	防鬆螺帽	LOCK NUT	4
04-5	B100558010	腳墊	STAND CUSHION	1	11	A020204131002	高壓泵浦 WH-2513F1	HIGH PRESSURE PUMP	1
04-6	BS21112300	六角螺帽	HEX NUT	1	11-1	B021701000	進水接頭	INLET CONNECTOR	1
04-7	BS32112300	彈簧華司	SPRING WASHER	1	11-2	1S50016040	內六角油塞 PT1/2	PLUG PT1/2	1
04-8	BS31210300	平面華司	WASHER	1	11-3	B070023200	自動洩壓總成	UNLOADING VALVE ASSY	1
05	B080758003	收折把手	HANDLE	1	11-4	B071810000	外部迴水接頭	OVERFLOW CONNECTOR	1
05-1	BS11210070200	六角螺絲	HEX SCREW	2	11-5	BK20201040	快速接頭 C4	QUICK CONNECTOR C4	1
05-2	BS31210307	平面華司	WASHER	4	11-6	BS11206060300	六角螺絲	HEX SCREW	1
05-3	BS22210300	防鬆螺帽	LOCK NUT	2	11-7	BS21206300	六角螺帽	HEX NUT	2
05-4	B100658000	電木螺絲	SCREW	2	12	B031258000	壓力錶省油器接頭	PRESURE GAUGE CONNECTOR	1
06	B120158000	法蘭盤	FLANGE	1	13	B031110000	壓力錶	PRESSURE GAUGE	1
06-1	BS16208025500	內六角螺絲	HEX SOCKET SCREW	4	14	B031358000	壓力錶排氣接頭	PRESSURE GAUGE CONNECTOR	1
06-2	BS33208400	安全華司	SAFETY WASHER	4	15	B031601000	球形閥 8.5mm	BALL VALVE 8.5mm	1
06-3	BS16206025200	內六角螺絲	SCREW	4	16	B250002014	省油器	PETROL SAVER	1

