



零件表PARTS LIST WH-2915E3

圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY
01	B080559003	收折台架	FRAME	1	07-3	BS17112013500	無頭內六角螺絲	SCREW	4
02	B080659003	輪軸	WHEEL SHAFT	1	08	B120259000	法蘭盤墊片	FLANGE BASE PLATE	1
02-1	BS11210065200	六角螺絲	HEX SCREW	2	08-1	BS16208045500	內六角螺絲	SCREW	4
02-2	BS22210300	防鬆螺帽	LOCK NUT	2	08-2	BS33208400	安全華司	SAFETY WASHER	4
02-3	BS31210301	平面華司	WASHER	2	09	B100360000	引擎襯套	SPACER RING	1
03	B081057000	固定輪	WHEEL	2	10	BA10090200	HONDA 引擎 9HP GX270	ENGINE HONDA 9HP GX270	1
03-1	BS70043000	開口銷	PIN	4	10-1	BS11210050200	六角螺絲	SCREW	4
03-2	B081350000	車輪護蓋	WHEEL COVER	2	10-2	BS31210200	平面華司	WASHER	8
03-3	B100150000	平面華司	WASHER	4	10-3	BS22210300	防鬆螺帽	LOCK NUT	4
04	B081159000	煞車輪	CASTER WHEEL WITH BREAK	1	12	A020204151001	高壓泵浦 WH-2915F1	HIGH PRESSURE PUMP WH-2915F1	1
04-1	BS11208025200	六角螺絲	HEX SCREW	4	13	B031358000	壓力錶排氣接頭	PRESSURE GAUGE CONNECTOR	1
04-2	BS31208302	平面華司	WASHER	8	13-1	B032259010	排氣開關	VALVE PLUG	1
04-3	BS22208300	防鬆螺帽	LOCK NUT	4	14	B070023200	自動洩壓總成	UNLOADING VALVE ASSY	1
05	B080759003	收折把手	HANDLE	1	14-1	B071810000	外部迴水接頭	OVERFLOW CONNECTOR	1
05-1	BS11210070200	六角螺絲	HEX SCREW	2	14-2	BK20201040	快速接頭 C4	QUICK CONNECTOR C4	1
05-2	BS31210307	平面華司	WASHER	4	14-3	BS11206060300	六角螺絲	HEX SCREW	1
05-3	BS22210300	防鬆螺帽	LOCK NUT	2	14-4	BS21206300	六角螺帽	HEX NUT	2
05-4	B100658000	電木螺絲	SCREW	2	15	B010359003	腳座	LEG	1
06	B120158000	法蘭盤	FLANGE	1	15-1	BS11210015222	六角螺絲附華司	HEX SCREW W/ WASHER	2
06-1	BS16208025500	內六角螺絲	SCREW	4	15-2	BS11210030200	六角螺絲	HEX SCREW	2
06-2	BS33208400	安全華司	SAFETY WASHER	4	15-3	BS31210200	平面華司	WASHER	4
06-3	BS16206025200	內六角螺絲	SCREW	4	15-4	BS22210300	防鬆螺帽	LOCK NUT	2
06-4	BS33206400	安全華司	SAFETY WASHER	4	16	B031259000	壓力錶省油器接頭	PRESURE GAUGE CONNECTOR	1
07	B120553020	連軸器-泵浦	FLEXIBLE COUPLING-PUMP (M)	1	16-1	B031111000001	壓力錶	PRESSURE GAUGE	1
07-1	B120453010	連軸器-引擎	FLEXIBLE COUPLING-ENGINE (F)	1	16-2	B250002014	省油器	PETROL SAVER	1
07-2	B120353000	連軸器內襯	BUSHING	6	16-3	B250002521	加油線組	PETROL SAVER WIRE	1

