



WH-3020E3
WH-4016E3

零件表PARTS LIST WH-3020E3 / WH-4016E3

圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY
01	B080560003	收折台架	FRAME	1	07-3	BS17112013500	無頭內六角螺絲	SCREW	4
02	B080660003	輪軸	WHEEL SHAFT	1	08	B120260000	法蘭盤墊片	FLANGE BASE PLATE	1
02-1	BS11210065200	六角螺絲	HEX SCREW	2	08-1	BS16208035300	內六角螺絲	SCREW	4
02-2	BS22210300	防鬆螺帽	LOCK NUT	2	08-2	BS33208400	安全華司	SAFETY WASHER	4
02-3	BS31210301	平面華司	WASHER	2	09	B100360000	引擎襯套	SPACER RING	1
03	B081057000	固定輪	WHEEL	2	10	BA10130200	HONDA 引擎 13HP GX390T2	HONDA ENGINE HONDA 13HP GX390T2	1
03-1	BS70043000	開口銷	PIN	4	10-1	B100460125	防震墊	CUSHION	4
03-2	B081350000	車輪護蓋	WHEEL COVER	2	10-2	BS31210301	平面華司	WASHER	8
03-3	B100150000	平面華司	WASHER	4	10-3	BS22210300	防鬆螺帽	LOCK NUT	8
04	B081159000	煞車輪	CASTER WHEEL WITH BREAK	1	11	A020208100	高壓幫浦 WH-3520FP	HIGH PRESSURE PUMP	1
04-1	BS11208020322	六角螺絲附華司	HEX SCREW W/ WASHER	4		A020208203	高壓幫浦 WH-5016FPE		
04-2	BS31208302	平面華司	WASHER	8	11-1	B100460022	防震圈(幫浦)	CUSHION (PUMP)	2
04-3	BS22208300	防鬆螺帽	LOCK NUT	4	11-2	BS31210301	平面華司	WASHER	2
05	B080760003	收折把手	HANDLE	1	11-3	BS22210300	防鬆螺帽	LOCK NUT	2
05-1	BS11210075300	六角螺絲	SCREW	2	12	B060619321	雙外牙接頭	CONNECTOR	1
05-2	BS31210307	平面華司	WASHER	4	12-1	B060019320	安全弁	SAFETY VALVE ASSY	1
05-3	BS22210300	防鬆螺帽	LOCK NUT	2	12-2	BK20201040	快速接頭 C4	QUICK CONNECTOR C4	1
05-4	B100658000	電木螺絲	SCREW	2	12-3	BS50016060	內六角塞頭 PT1/2	PLUG PT1/2	1
06	B120160000	法蘭盤	FLANGE	1	12-4	BG10138018620	O形環	O-RING	1
06-1	BS16210035300	內六角螺絲	SCREW	4	12-5	B062819311	迴水接頭	OVERFLOW CONNECTOR	1
06-2	BS33210400	安全華司	SAFETY WASHER	4	13	B031260011	壓力錶省油器接頭	PRESSURE GAUGE CONNECTOR	1
06-3	BS16208030500	內六角螺絲	SCREW	4	13-1	B031117010001	壓力錶	PRESSURE GAUGE	1
06-4	BS33208400	安全華司	SAFETY WASHER	4	13-2	B250002231	省油器+加油線組	PETROL SAVER W/WIRE	1
07	B120553020	連軸器-泵浦	FLEXIBLE COUPLING-PUMP	1	13-3	B032224201	排氣開關組	AIR RELEASE ASSY	1
07-1	B120453010	連軸器-引擎	FLEXIBLE COUPLING-ENGINE	1	13-4	BK31502022	大小內外接頭	ADAPTER	1
07-2	B120353000	連軸器內襯	BUSHING	6	14	1S50016040	內六角油塞 PT1/2	PLUG PT1/2	1

