




WH-1038
WF-1038

零件表PARTS LIST WH-1038 / WF-1038

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
01	B010102032	曲軸箱	CRANKCASE	1		09-1	B010924100	全密曲軸油封 (單邊用)	END COVER OIL SEAL (FOR 1-END)	1	
01-1	B012901110	汽缸銷	SET PIN	2		10	B011008000	曲軸油封蓋 (單邊用)	CRANKSHAFT OIL SEAL COVER (FOR 1-END)	1	
02	B010208010	柱塞油封	PISTON OIL SEAL	3		10-1	B011002200	曲軸油封蓋 (單邊用)	CRANKSHAFT OIL SEAL COVER (FOR 1-END)	1	
03	B010302040	腳座	CRANKCASE STAND	2		10-2	BS12206010200	大扁頭螺絲	SCREW	8	
03-1	BS11210015222	六角螺絲附華司	HEX SCREW W/ WASHER	4		10-3	B011102111	曲軸油封蓋 (套筒)	CRANKSHAFT OIL SEAL COVER (CONE)	1	
03-2	BS31210201	平面華司	WASHER	4		11	B011602531	曲軸箱後蓋	REAR COVER	1	
04A	B013002201	柱塞組	CERAMIC PISTON ASSY	3		11-1	B011702000	後蓋迫緊	REAR COVER PACKING	1	
04-1	B013102200	柱塞桿	PISTON ROD	1		11-2	BS12206016200	大扁頭螺絲	SCREW	5	
04-2	B013208001	柱塞套	CERAMIC PISTON SLEEVE	1		12A	N/A	油鏡組	OIL WINDOW ASSY	1	
04-3	B013408000	柱塞套固定螺帽	PISTON SET NUT	1		12	B012201020	油鏡	OIL WINDOW	1	
04-4	B013508002	柱塞套平墊圈	GASKET	1		12-1	BG10234028700	O形環	O-RING	1	
04-5	BG10140018500	O形環	O-RING	1		13A	B011801001	排油螺絲組	DRAINAGE SCREW ASSY	1	
04-6	BG30156019	背托環	BACK-UP RING	1		13	B011801000	排油螺絲	DRAINAGE SCREW	1	
04-7	B013308000	柱塞套固定螺絲	PISTON SET SCREW	1		13-1	BG10110015	O形環	O-RING	1	
04-8	B013508010	柱塞套透氣墊圈	GASKET	1		14	B011901014	加油蓋組	OIL INLET COVER ASSY	1	
05	B010502111	柱塞銷	PISTON PIN	3		15	B020102200	汽缸	CYLINDER	1	
06A	B010602002	連桿組	CONNECTING ROD	3		16	B020302202	U迫緊底座	U-PACKING SEAT	3	
06-1	BS11206030500	六角螺絲	HEX SCREW	6		17	B020302200	U迫緊	U-PACKING	3	
06-2	BS32206501	彈簧華司	SPRING WASJER	6		18	B020302201	U迫緊墊片	U-PACKING SPACER	3	
07	B010709010	軸承	BEARING	2		19	B021202200	迫緊中間環	U-PACKING SPACER RING	3	
08A	B010809540	曲軸 (雙邊出軸)	DOUBLE-END CRANKSHAFT	1		20	B021002200	防水油封	WATERPROOF OIL SEAL	3	
08	B010809530	曲軸 (單邊出軸)	SINGLE-END CRANKSHAFT			21	B021102200	迫緊上環	PACKING UPPER RING	3	
08-1	B012101110	曲軸鍵	CRANKSHAFT KEY	1		22	BG10370042	O形環	O-RING	3	
09	B010902000	曲軸油封 (雙邊用)	CRANKSHAFT OIL SEAL (FOR 2-END)	2		23	BS15210043200	雙頭牙螺絲	DOUBLE-END SCREW	8	
10	B011008000	曲軸油封蓋 (雙邊用)	CRANKSHAFT OIL SEAL COVER (FOR 2-END)	2		23-2	BS32210200	彈簧華司	SPRING WASHER	8	
09	B010902000	曲軸油封 (單邊用)	CRANKSHAFT OIL SEAL (FOR 1-END)	1		23-3	BS21210201	六角螺帽	NUT	8	

零件表PARTS LIST WH-1038 / WF-1038

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
24	B020602200	迫緊防脫片	SET PLATE WH-1038	1		ACC.	B150623400	過濾網申目	FILTER SOCKET	1	
25A	B040008001	進水活門組	INLET VALVE ASSY	3		ACC.	B150909110	過濾網	FILTER	1	
25-1	B040308010	進水活門帽	INLET VALVE CAGE	3		ACC.	BP11822243	皮帶輪 10B2*24*5 (外銷用)	PULLEY 10B2*24*5 (EXPORT ONLY)	1	
25-2	BJ20202000	進水活門彈簧	INLET VALVE SPRING	3		ACC.	BS11112032121	皮帶輪螺絲 (外銷用)	PULLEY SET BOLT (EXPORT ONLY)	1	
25-3	B040108000	活門塞	VALVE PLUG	3							
25-4	B040208010	進水活門座	INLET VALVE SEAT	3							
25-5	BG10220027020	O形環	O-RING	3							
25-6	BG30228026800	進水背托環	INLET VALVE BACK-UP RING	3							
26	B021308010	進水固定螺絲	INLET VALVE SET BOLT	3							
26-1	BG10250032030	O形環	O-RING	3							
27A	B040008011	出水活門組	OUTLET VALVE ASSY	3							
27-1	B040308000	出水活門帽	OUTLET VALVE CAGE	3							
27-2	BJ20801000	出水活門彈簧	OUTLET VALVE SPRING	3							
27-3	B040108000	活門塞	VALVE PLUG	3							
27-4	B040208000	出水活門座	OUTLET VALVE SEAT	3							
28	BG10220027020	O形環	O-RING	3							
29	B021308000	出水固定螺絲	OUTLET VALVE SET BOLT	3							
29-1	BG30258031900	出水背托環	OUTLET BACK-UP RING	3							
29-2	BG10250032030	O形環	O-RING	3							
30	B021723400	進水接頭	INLET CONNECTOR	1							
31	B031109000	壓力錶	PRESSURE GAUGE	1							
32	B031209000	壓力錶接頭	PRESSURE GAUGE CONNECTOR	1							
60A	B070008001	自動洩壓總成 (WH-1038)	UNLOADING VALVE ASSY (WH-1038)	1							
60B	B070008002	自動洩壓總成 (WF-1038)	UNLOADING VALVE ASSY (WF-1038)			*60A零件表及展開圖請參閱第4頁。			*60A parts list & diagram please refer to page 4.		
ACC.	B150102004	吸水管組 1"*10 尺	INLET HOSE ASSY 1"*10 FT	1		*60B零件表及展開圖請參閱第5頁。			*60B parts list & diagram please refer to page 5.		
ACC.	B150201001	迴水管組 1/2"*9尺	OVERFLOW HOSE ASSY 1/2"*9FT	1							

零件表PARTS LIST

自動洩壓總成 B070008001 UNLOADING VALVE ASSEMBLY

WH-1038/2024F1系列/2124F1系列用

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
01	B070109000	洩壓汽缸套	UNLOADING VALVE CYLINDER	1		14	BS32108200	彈簧華司	SPRING WASHER	4	
02	BJ50901000	洩壓輔助彈簧	AUXILIARY SPRING	1		30	B071209000	出水接頭	OUTLET CONNECTOR	1	
03A	B070609001	柱塞活門組	PISTON VALVE ASSY	1		32	B051801110	迴水接頭	OVERFLOW COUPLING	1	
03-1	B070609000	柱塞活門體	PISTON VALVE BODY	1							
03-2	BG10150020020	O形環	O-RING	2							
03-3	BG30162020	背托環	BACK-UP RING	3							
03-4	B070709000	止水閥塞	VALVE PLUG	1							
03-5	BJ30901000	球閥固定彈簧	SPRING	1							
03-6	B070809000	球閥固定套	BALL VALVE SEAT	1							
04A	B070209000	迴水座	OVERFLOW CHAMBER	1							
04-1	B071109051	固定環	SET RING	1							
04-2	BS17106005300	無頭內六角螺絲	HEX SCREW	2							
05	BG10108015640	O形環	O-RING	2							
06	B070509000	壓力閥桿	VALVE ROD	1							
07	B070909000	消音片	DAMPER PLATE	1							
08	B070309000	陶瓷球閥	CERAMIC BALL VALVE	1							
09A	B070409001	壓力閥座組	VALVE SEAT ASSY	1							
09-1	B070409000	壓力閥座	VALVE SEAT	1							
09-2	BG10200025020	O形環	O-RING	1							
09-3	BG10170022020	O形環	O-RING	1							
09-4	BG30183022310	背托環	BACK-UP RING	1							
10	B071311000	彈簧上座	SPRING SEAT (UPPER)	1							
11	BJ41101000	調壓彈簧	PRESSURE REGULATING SPRING	1							
12	B071409001	彈簧下座	SPRING SEAT	1							
13	B071709000	調壓螺帽	PRESSURE REGULATING KNOB	1							
14	BS14108022100	圓頭螺絲	SCREW	4							

30 B070008001
適用機型FOR:
WH-1038
WH-2024F1
WH-2030F1
WH-2124F1
WH-2130F1
WH-2135F1

零件表PARTS LIST

自動洩壓總成 B070008002 / UNLOADING VALVE ASSEMBLY

WF-1038/2024F1/2030F1/2513F1用

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
01	B070109000	洩壓汽缸套	UNLOADING VALVE CYLINDER	1	
04A	B070209000	迴水座	OVERFLOW CHAMBER	1	
04-1	B071109051	固定環	SET RING	1	
04-2	BS17106005300	無頭內六角螺絲	HEX SCREW	2	
05	BG10108015640	O形環	O-RING	2	
06	B070509000	壓力閥桿	PRESSURE VALVE ROD	1	
07	B070909000	消音片	DAMPER PLATE	1	
08	B070309000	陶瓷球閥	CERAMIC BALL VALVE	1	
09A	B070409001	壓力閥座組	PRESSURE VALVE SEAT	1	
09-1	B070409000	壓力閥座	PRESSURE VALVE SEAT	1	
09-2	BG10200025020	O形環	O-RING	1	
09-3	BG10170022020	O形環	O-RING	1	
09-4	BG30183022310	背托環	BACK-UP RING	1	
10	B071311000	彈簧上座	SPRING SEAT (UPPER)	1	
11	BJ41101000	調壓彈簧	PRESSURE REGULATING SPRING	1	
12	B071409001	彈簧下座	SPRING SEAT	1	
13	B071709000	調壓螺帽	PRESSURE REGULATING KNOB	1	
14	BS14108022100	圓頭螺絲	SCREW	4	
14	BS32108200	彈簧華司	SPRING WASHER	4	
30	B071209000	出水接頭	OUTLET CONNECTOR	1	
32	B051801110	迴水接頭	OVERFLOW COUPLING	1	
			2025.02V.		

