



配件	
19	

**WM-1001B-5**  
**WM-10005B-5**  
**WM-1001B-6**  
**WM-10005B-6**

零件表PARTS LIST WM-10005B-5 / WM-1001B-5 / WM-10005B-6 / WM-1001B-6

圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY
01	BA21400216030	馬達 (10005B-5/230V)	MOTOR (10005B-5/230V)	1	03A	1019203000	柱塞軸套	HOUSING	1
	BA20400216010	馬達 (10005B-6/110V)	MOTOR (10005B-6/110V)		03B	B019248000	引擎培林	BEARING	2
	BA20400216030	馬達 (10005B-6/220V)	MOTOR (10005B-6/220V)		03-1	BG10636068410	O形環	O-RING	1
	BA21400316000	馬達 (1001B-5/230V)	MOTOR (1001B-5/230V)		03-2	B019215010	止逆彈簧固定座	SPRING DISK	2
	BA20400316000	馬達 (1001B-6/110V)	MOTOR (1001B-6/110V)		03-3	B019214013	柱塞滑靴組 (10005B)	PISTON ASSY (10005B)	2
	BA20400316020	馬達 (1001B-6/220V)	MOTOR (1001B-6/220V)			B019214012	柱塞滑靴組 (1001B)	PISTON ASSY (1001B)	
01-1	N/A	電器盒下蓋	LOWER COVER	1	03-4	BJ00106272	柱塞彈簧	PISTON SPRING	2
01-2	D020203003	電器盒上蓋	UPPER COVER	1	03-5	B019213000	柱塞油封	PISTON OIL SEAL	2
01-3	D020201112	電容器 (4uF/450V)	CONDENSER (10005B-5/6)	1	04	B019202020	汽缸	CYLINDER	1
	D020201111	電容器 (18uF/250V)	CONDENSER (10005B-6)		04-1	B019211000	U形迫緊	U-PACKING	4
	D020201104	電容器 (5uF/450V)	CONDENSER (1001B-5/6)		04-2	B019210000	防水油封套	WATERPROOF SEAL COLLAR	2
	D020201103	電容器 (16uF/250V)	CONDENSER (1001B-6)		04-3	BG10212025500	O形環	O-RING	2
01-4	B130963100	過電流斷路器 (50HZ/3A)	CIRCUIT BREAKER (50HZ/3A)	1	04-4	B019212000	墊圈	SPACER	2
	B130963110	過電流斷路器 (60HZ/5A)	CIRCUIT BREAKER (60HZ/5A)		04-5	B019209010	O型環固定環	SET RING	1
01-5	B100750000	溫控開關防水套	COVER	1	04-6	BG10025005	O形環	O-RING	1
01-6	B130563021	電源開關	POWER SWITCH	1	04-7	BG10080010400	O形環	O-RING	4
01-8	N/A	連接線	CONNECTING WIRE	1	04-8	BG10088012600	O形環	O-RING	2
02	B019401000	偏心盤 (10005B)	WOBBLE PLATE (10005B)	1	05	B019201020	進出水室	MANIFOLD	1
	B019219000	偏心盤 (1001B)	WOBBLE PLATE (1001B)		05-1	B019205011	調壓螺帽	PRESSURE REGULATING KNOB	1
02-1	B019221010	軸承油封	BEARING OIL SEAL	1	05-2	B019206000	彈簧上座	SPRING SEAT (UPPER)	2
02-2	B019220000	推力墊圈	GASKET	2	05-3	BJ00106253	調壓彈簧	PRESSURE REGULATING SPRING	1
02-3	B019217000	滾針軸承	BALL BEARING	2	05-4	B019204000	安全弁接頭	CONNECTOR	1
02-4	B019218000	培林支撐套	BEARING SPACER	1	05-5	BG10130018040	O形環	O-RING	1
02-5	B019216010	平面軸承上片	BEARING PLATE (UPPER)	1	05-6	B019207013	壓力閥	PRESSURE VALVE	1
02-6	BS17108010500	無頭內六角螺絲	SCREW	1	05-7	BG10048008600	O形環	O-RING	2
03	B019203011	軸箱組(含引擎培林)	HOUSING W/ BEARING	1	05-8	B019208001	壓力閥座	PRESSURE VALVE SEAT	1

零件表PARTS LIST WM-10005B-5 / WM-1001B-5 / WM-10005B-6 / WM-1001B-6

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
05-9	BG10088012600	O形環	O-RING	1		18-5	BS11206012300	六角螺絲	SET BOLT	2	
06A	B029400036	加油蓋組	OIL INLET COVER	1		19	BK31402030	管牙插心	ADAPTER	1	
07A	B011801001	排油螺絲組	DRAINAGE SCREW ASSY	1							
07	B011801000	排油螺絲	DRAINAGE SCREW	1							
07-1	BG10110015	O形環	O-RING	1							
08	B019229020	油鏡	OIL WINDOW	1							
08-1	BG10158020600	O形環	O-RING	1							
09A	B040063043	活門組	VALVE ASSY	4							
09-1	B040363110	活門帽	VALVE CAGE	4							
09-2	BJ00106290	活門彈簧	SPRING	4							
09-3	B040163111	活門塞	VALVE PLUG	4							
09-4	B040263110	活門座	VALVE SEAT	4							
10	BS32108300	彈簧華司	SPRING WASHER	3							
11	BS16206020300	內六角螺絲	HEX SCREW	7							
12	BS32205300	彈簧華司	SPRING WASHER	4							
13	BS16205015300	內六角螺絲	HEX SCREW	4							
14	B090563010	電源線 (雙扁插頭)	POWER CORD (2-FLAT-PIN PLUG)	1							
	B110563010	電源線固定夾 & 螺帽	CORD BINDER & NUT	1							
15	BS21206200	六角螺帽	NUT	4							
16	BS31108200	平面華司	WASHER	4							
17	B100563140	腳墊	CUSHION	4							
18	B019110000	把手片	HANDLE PLATE	1							
18-1	BS11110089200	六角螺絲	SET BOLT	1							
18-2	BS21110100	六角螺帽	NUT	1							
18-3	BS31208200	平面華司	WASHER	1							
18-4	B019113000	活動把手	HANDLE	1							

2020.03V