



WN-1002-5 WN-1002-6
 WN-1003-5 WN-1003-6
 WN-1004-5 WN-1005-6

零件表PARTS LIST WN-1002-5 / WN-1003-5 / WN-1004-5 / WN-1002-6 / WN-1003-6 / WN-1005-6

圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY
01	BA20800516040	馬達 (1002/3-5)	MOTOR (1002/3-5)	1	02-4	B019305000	培林支撐套	BEARING SPACER	1
	BA20601016000	馬達 (1004-5)	MOTOR (1004-5)		02-5	B019105021	平面軸承片	BEARING PLATE (UPPER)	1
	BA20600616100	馬達 (1002-6)	MOTOR (1002-6)		02-6	BS17108010500	無頭內六角螺絲	SCREW	1
	BA20600616120	馬達 (1003-6)	MOTOR (1003-6)		03A	B019501001	軸箱組(含引擎培林)	HOUSING W/ BEARING	1
	BA20401016100	馬達 (1005-6)	MOTOR (1005-6)		03	1019501001	軸箱	HOUSING	1
01-1/-2	N/A	電器盒	CONTROL BOX	1	03-1	1019508000	引擎培林	BEARING	3
01-3	D020201117	電容器 (18uF/450V)	CONDENSER (1002/3/4-5)	1	03-2	B019503000	柱塞油封	OIL SEAL	3
	D020201108	電容器 (20uF/450V)	CONDENSER (1002/3-6)		03-3	BG10995103510	O形環	O-RING	1
	D020201107	電容器 (50uF/250V)	CONDENSER (1005-6)		03-4	BS32108300	彈簧華司	SPRING WASHER	4
01-4	N/A	過電流斷路器	CIRCUIT BREAKER	1	03-5	B019509000	軸箱固定螺絲	SCREW	2
01-5	N/A	防水套	COVER	1	03-6	B019509020	軸箱固定螺帽	NUT	2
01-6	B130563021	電源開關	POWER SWITCH	1	03-7	BS16108025500	內六角螺絲	HEX SCREW	2
01-7	B110565000	電源線固定夾	CORD BINDER & NUT	1	04A	B019304022	柱塞滑靴組5L(1002-5)	PISTON ASSY (1002-5)	3
01-8	N/A	連接線	CONNECTING WIRE	1		B019304023	柱塞滑靴組8L(1003/4-5)	PISTON ASSY (1003/4-5)	
01-9	N/A	電器盒固定螺絲	SCREW	4		B019304021	柱塞滑靴組3L(1002-6)	PISTON ASSY (1002-6)	
01-10	N/A	電器盒上蓋固定螺絲	SCREW	1		B019304022	柱塞滑靴組5L(1003/5-6)	PISTON ASSY (1003/5-6)	
01-11	B100463031	防震墊片 (50HZ)	GASKET (50HZ)	1	05	B019505000	止逆彈簧固定座	SPRING SEAT	3
	B100463030	防震墊片 (60HZ)	GASKET (60HZ)		06	BJ00106050	柱塞彈簧	SPRING	3
01-12	B019316000	出線皮	PACKING	1	07A	B011801001	排油螺絲組	DRAINAGE SCREW ASSY	1
02	B019312010	偏心盤 (1002-5)	WOBBLE PLATE (1002-5)	1	07	B011801000	排油螺絲	DRAINAGE SCREW	1
	B019312020	偏心盤 (1003/4-5)	WOBBLE PLATE (1003/4-5)		07-1	BG10110015	O形環	O-RING	1
	B019312000	偏心盤 (1002-6)	WOBBLE PLATE (1002-6)		08A	B019229003	油鏡組	OIL WINDOW ASSY	1
	B019312010	偏心盤 (1003/5-6)	WOBBLE PLATE (1003/5-6)		08	B019229020	油鏡	OIL WINDOW	1
02-1	B019313000	軸承油封	BEARING OIL SEAL	1	08-1	BG10158020600	O形環	O-RING	1
02-2	B019118010	推力墊圈	GASKET	2	09A	B011901014	加油蓋組	OIL INLET COVER ASSY	1
02-3	B019114010	平面軸承	BEARING	2	10	B019504000	防水油封套	WATERPROOF OIL SEAL	3

零件表PARTS LIST WN-1002-5 / WN-1003-5 / WN-1004-5 / WN-1002-6 / WN-1003-6 / WN-1005-6

圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY	圖號 NO.	編號 CODE	名稱	DESCRIPTION	Q'TY
10-1	BG10300034	O形環	O-RING	3	21	B019516000	調壓螺帽	PRESSURE REGULATING KNOB	1
11	B019506000	防水迫緊	WATERPROOF PACKING	3	22	B019515000	彈簧上座	SPRING SEAT (UPPER)	2
11-1	B019507000	防水迫緊墊片	WATERPROOF PACKING GASKET	3	23	BJ00106120	調壓彈簧	PRESSURE REGULATING SPRING	1
12	B019504020	U迫緊套	U-PACKING COLLAR	3	24	B019512000	安全弁接頭	SAFETY VALVE COUPLING	1
12-1	BG10290033	O形環	O-RING	3	24-1	BG10140018500	O形環	O-RING	1
13	B019310003	墊圈	GASKET	3	25	B019513000	壓力閥桿	PRESSURE VALVE ROD	1
14	B019309001	U型迫緊	U-PACKING	3	25-1	BG10075011500	O形環	O-RING	2
15A	B040063060	進出水活門組	VALVE ASSY	3	26	B019514000	壓力閥座	PRESSURE VALVE SEAT	1
15	B040263130	進出水活門座	VALVE SEAT	3	26-1	BG10098013600	O形環	O-RING	1
15-1	BG10210025040	O形環	O-RING	3	27	B090563000	電源線 (雙扁插頭)	POWER CORD (2-FLAT-PIN PLUG)	1
15-2	B040163062	進水活門塞	INLET VALVE PLUG	3	28A	B160263021	把手組	HANDLE ASSY	1
15-3	BJ26301030	進水活門彈簧	INLET VALVE SPRING	3	28	B019110000	把手片	HANDLE PLATE	1
15-4	B040363051	進水活門帽	INLET VALVE CAGE	3	28-1	BS11110089200	六角螺絲	SET BOLT	1
15-5	BG10170021040	O形環	O-RING	3	28-2	BS21110100	六角螺帽	NUT	1
15-6	B040163024	活門塞	VALVE PLUG	3	28-3	BS31208200	平面華司	WASHER	1
15-7	BJ26301021	活門彈簧	VALVE SPRING	3	28-4	B019113000	活動把手	HANDLE	1
15-8	B040363060	出水活門帽	OUTLET VALVE CAGE	3	28-5	BS11108016200	六角螺絲	SET BOLT	2
16	B019502000	汽缸	CYLINDER	1	29	B100563010	腳墊	CUSHION	4
16-1	BS16112045500	內六角螺絲	HEX SCREW	3					
16-2	BS16108045501	內六角螺絲	HEX SCREW	2					
17	B019510000	止水塞頭	PLUG	1					
18	BK31404010	管牙插心	ADAPTER	1					
19	B019511000	外迴水接頭	EXTERNAL OVERFLOW COUPLING	1					
19-1	BG10100014	O形環	O-RING	1					
19-2	BG10070011	O形環	O-RING	1					
20	B019511020	內迴水接頭	INTERNAL OVERFLOW COUPLING	1					

2020.03V.