




零件表PARTS LIST WS-1470 / WS-1770 / WS-1770海水SEA


圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
01	B010125002	曲軸箱	CRANKCASE	1		07-1	B012122000	曲軸鍵	CRANKSHAFT KEY	1	
01-3	B100519050	圓內塞頭1/4"	PLUG 1/4"	3		08	B010722001	軸承	BEARING	2	
01-5	B012919000	汽缸銷	SET PIN	2		09	B011022002	軸承油封蓋	CRANKSHAFT OIL SEAL COVER	2	
02	B010222000	柱塞油封	PISTON OIL SEAL	3		09-1	BG10900095200	O形環	O-RING	4	
03	B010322050	腳座	CRANKCASE STAND	2		09-2	BS16208025300	內六角螺絲	SCREW	8	
03-1	BS11214030300	六角螺絲	SCREW	4		09-3	BS32208300	彈簧華司	SPRING WASHER	8	
03-2	BS32214300	彈簧華司	SPRING WASHER	4		09-4	BS31208301	平面華司	WASHER	8	
03-3	BS31214201	平面華司	WASHER	4		09-5	B012622050	軸承蓋平墊圈	SHIM	4	
04-1	B013425000	固定螺帽[S304](1470/1770)	NUT [S304] (1470/1770)	3		10	B010922000	曲軸油封	CRANKSHAFT OIL SEAL	2	
	B013425001	固定螺帽[雙相鋼](1770海水)	NUT [DSS] (1770 SEA)			11	B011122002	曲軸邊蓋	CRANKSHAFT COVER	1	
04-2	B013525000	柱塞套平墊圈[S316]	GASKET [S316]	3		11-1	BS16206016300	內六角螺絲	SCREW	4	
04-3	BG10095014500	O形環	O-RING	3		11-2	BS32206300	彈簧華司	SPRING WASHER	4	
04-4	BG30099013800	背托環	BACK-UP RING	3		11-3	BS31206310	平面華司	WASHER	4	
04-5	B013325000	柱塞套固定螺絲[S304]	PISTON SET SCREW [S304]	3		12	B011622002	曲軸箱後蓋	REAR COVER	1	
04-6	B013225000	柱塞套	CERAMIC PISTON SLEEVE	3		12-1	BG12091216200	O形環	O-RING	1	
04-7	B013522150	柱塞套透氣墊圈[S316]	GASKET [S316]	3		13	BS16208025300	內六角螺絲	SCREW	8	
04-8	B013522151	柱塞套擋水墊圈[S316]	GASKET[S316]	3		13-1	BS32208300	彈簧華司	SPRING WASHER	8	
04-9	B013122151	柱塞桿	PISTON ROD	3		13-2	BS31208306	平面華司	WASHER	8	
05	B010522000	柱塞銷	PISTON PIN	3		14	B012219100	油鏡	OIL WINDOW	1	
05-1	BS41015010	扣環	BUCKLE RING	6		14-1	BG10234028700	O形環	O-RING	1	
06A	B010622002	連桿組	CONNECTING ROD ASSY	3		15	B011823000	排油螺絲	DRAINAGE SCREW	1	
06	N/A	連桿	CONNECTING ROD	3		15-1	BG10130019	O形環	O-RING	1	
06-1	BS11210050500	六角螺絲	SCREW	6		16	B011901014	加油蓋組	OIL INLET COVER ASSY	1	
06-2	BS31210500	平面華司	WASHER	6		16-1	BG10203025500	O形環	O-RING	1	
06-3	B014322000	螺絲防鬆片	LOCK WASHER	3		17	B031425000	汽缸後座[S316](1470/1770)	INLET MANIFOLD [S316] (1470/1770)	1	
07	B010822050	曲軸	CRANKSHAFT	1			B031425010	汽缸後座[雙相鋼](1770海水)	INLET MANIFOLD [DSS] (1770 SEA)		

零件表PARTS LIST WS-1470 / WS-1770 / WS-1770海水SEA

圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY		圖號 NO.	編號 CODE	名 稱	DESCRIPTION	Q'TY	
17-1	BG10270034	O形環	O-RING	3		25-2	BJ22501000	活門彈簧[S304]	VALVE SPRING [S304]	6	
17-2	BS16212040300	內六角螺絲	SCREW	4		25-3	B040125002	活門塞[S316](1470/1770)	VALVE PLUG [S316] (1470/1770)	6	
18	B021125100	防水油封套[S316](1470/1770)	OIL SEAL COLLAR [S316] (1470/1770)	3			B040125001	活門塞[雙相鋼](1770海水)	VALVE PLUG [DSS] (1770SEA)		
	B021125101	防水油封套[雙相鋼](1770海水)	OIL SEAL COLLAR [DSS] (1770 SEA)			25-4	B040225000	活門座[S316](1470/1770)	VALVE SEAT [S316] (1470/1770)	6	
18-1	BG10410046	O形環	O-RING	3			B040225001	活門座[雙相鋼](1770海水)	VALVE SEAT [DSS] (1770SEA)		
18-2	B024025000	防水油封墊片(1470/1770海水)	OIL SEAL GASKET (1470/1770SEA)	3		25-5	BG30308034800	背托環	BACK-UP RING	6	
18-3	B021025010	防水油封(1470/1770海水)	WATERPROOF OIL SEAL (1470/1770SEA)	3		25-6	BG10290034	O形環	O-RING	6	
	B021025000	防水油封(1770)	WATERPROOF OIL SEAL (1770)			26	B021325000	活門固定螺絲[S316](1470/1770)	VALVE BOLT [S316] (1470/1770)	6	
19	B021225000	V迫緊套[NOK](1470)	V-PACKING COLLAR [NOK] (1470)	3			B021325010	活門固定螺絲[雙相鋼](1770海水)	VALVE BOLT [DSS] (1770SEA)		
20	B020325000	V迫緊[NOK](1470)	V-PACKING [NOK] (1470)	12		26-1	BG30360041900	背托環	BACK-UP RING	6	
21	B020225000	V迫緊底座[S316](1470)	V-PACKING SEAT [S316] (1470)	3		26-2	BG10345041500	O形環	O-RING	6	
19A	B021225002	V迫緊套	V-PACKING COLLAR	3		27	BJ22501210	活門輔助彈簧	VALVE SPRING [S304]	6	
20A	B020325001	V迫緊	V-PACKING	6		28	B040925000	活門帽保護片	SET PLATE [S304]	6	
21A	B020225002	V迫緊底座[S316](1470/1770)	V-PACKING SEAT [S316] (1470/1770)	3		29	B021725000	進水接頭[S304]	INLET CONNECTOR [S304]	1	
	B020225003	V迫緊底座[雙相鋼](1770海水)	V-PACKING SEAT [DSS] (1770SEA)			30	B023518000	安全弁接頭	SAFETY VALVE CONNECTOR	1	
22	BJ62501000	V迫緊彈簧[S304]	V-PACKING SPRING [S304]	3		*31	B060022051	安全弁 [S316]	SAFETY VALVE ASSY [S316]	1	
23	B021125000	V迫緊上環[S316](1470/1770)	PACKING UPPER RING [S316] (1470/1770)	3		32	BS50032001	外六角塞頭 PT1-1/4"[S304]	PLUG PT1-1/4" [S304]	1	
	B021125001	V迫緊上環[雙相鋼](1770海水)	PACKING UPPER RING [DSS] (1770SEA)			33	B031225000	壓力錶接頭[S304]	PRESSURE GAUGE CONNECTOR[S304]	1	
23-1	BG10384044600	O形環	O-RING	6		34	B031125000	壓力錶	PRESSURE GAUGE	1	
23-2	BG30397044800	背托環	BACK-UP RING	6							
24	B020125000	汽缸前座[S316](1470/1770)	DISCHARGE MANIFOLD [S316] (1470/1770)	1							
	B020125010	汽缸前座[雙相鋼](1770海水)	DISCHARGE MANIFOLD [DSS] (1770SEA)								
24-1	BS16212070300	內六角螺絲	SCREW	6							
25	B040025003	活門組[S316](1470/1770)	VALVE ASSY [S316] (1470/1770)	6							
	B040025002	活門組[雙相鋼](1770海水)	VALVE ASSY [DSS] (1770SEA)			*31 零件表及展開圖請參閱第4頁。			*31 parts list & diagram please refer to page 4.		
25-1	B040325000	活門帽	VALVE CAGE	6					2025.03V		

零件表PARTS LIST 安全弁 B060022051 / SAFETY VALVE ASSY

WS-1470/1770用

[illegible]

B060022051
適用機型 FOR:
WS-1470
WS-1770
WS-1770海水SEA